

MicroVAX 3100 Platform

BA42-B Enclosure Maintenance

Order Number: EK-A0511-MG.001

September 1992

This manual provides reference, installation, and maintenance information for the BA42-B enclosure. The MicroVAX 3100 Model 40, Model 80, and Model 90 systems use this enclosure.

Revision Information: This is a revised manual.

Digital Equipment Corporation
Maynard, Massachusetts

September 1992

The information in this document is subject to change without notice and should not be construed as a commitment by Digital Equipment Corporation. Digital Equipment Corporation assumes no responsibility for any errors that may appear in this document.

No responsibility is assumed for the use or reliability of software on equipment that is not supplied by Digital Equipment Corporation or its affiliated companies.

Restricted Rights: Use, duplication, or disclosure by the U.S. Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013.

© Digital Equipment Corporation 1992.

All Rights Reserved.

The postpaid Reader's Comments forms at the end of this document request your critical evaluation to assist in preparing future documentation.

The following are trademarks of Digital Equipment Corporation: DEC, Digital, MicroVAX, ThinWire, VAX DOCUMENT, VMS, and the DIGITAL logo.

This document was prepared using VAX DOCUMENT, Version 2.1.

Contents

Preface	ix
1 Enclosure Description	
1.1 Mass Storage Device Areas	1-3
1.2 Controls, Indicators, Ports, and Connectors	1-3
1.3 Power and Signal Distribution	1-7
1.4 Air Circulation	1-10
1.5 Configuration Guidelines	1-10
1.5.1 Memory	1-10
1.5.1.1 Model 40 Memory Configurations	1-10
1.5.1.2 Model 80 Memory Configurations	1-12
1.5.1.3 Model 90 Memory Configurations	1-14
1.5.2 Communications Options	1-16
1.5.3 Mass Storage Devices	1-20
2 Installation	
2.1 Preparing the Site	2-1
2.1.1 Dimensions	2-1
2.1.2 Additional Equipment	2-2
2.1.3 Operating Environment	2-3
2.1.4 Electrostatic Discharge	2-3
2.1.5 Heat Dissipation	2-3
2.1.6 Temperature, Humidity, and Altitude Ranges	2-3
2.1.7 Electrical Requirements	2-5
2.2 Unpacking the System	2-5
2.3 Installing the BA42-B System	2-7
2.3.1 Placing the BA42-B Enclosure	2-7
2.3.2 Identifying the Ports and Connectors on the System Unit ...	2-7
2.3.3 Connecting the Console Terminal	2-7
2.3.4 Connecting the ThinWire Terminator or Loopback Connector	2-10

2.3.5	Connecting the System Unit Power Cord	2-13
2.3.6	Turning On the System	2-14

3 Removing and Replacing FRUs

3.1	Removing the Enclosure Cover	3-5
3.2	Removing an MS44 or MS44L Memory Module	3-6
3.3	Removing an RZ-Series Disk Drive from the Upper Drive-Mounting Shelf	3-10
3.3.1	Separating the Support Plate from an RZ23L, RZ24, or RZ24L Disk Drive	3-11
3.3.2	Separating the Mounting Bracket from an RZ25, RZ26, or RZ35 Disk Drive	3-13
3.3.3	Setting the SCSI ID on the Replacement Disk Drive	3-14
3.4	Removing the Upper Drive-Mounting Shelf	3-19
3.5	Removing an RZ-Series Disk Drive from the Lower Drive-Mounting Shelf	3-21
3.6	Removing the RX26 Diskette Drive Assembly	3-23
3.6.1	Removing the RX26 FDI/SCSI Board	3-25
3.6.2	Separating the RX26 Diskette Drive from the Mounting Bracket	3-26
3.6.3	Setting the SCSI ID on the Replacement RX26 FDI/SCSI Board	3-27
3.7	Removing a TZ30 Tape Drive	3-29
3.7.1	Separating the TZ30 Tape Drive from the Mounting Bracket	3-31
3.7.2	Setting the SCSI ID on the Replacement TZ30 Tape Drive	3-32
3.8	Removing a TZK10 Tape Drive	3-33
3.8.1	Separating the TZK10 Tape Drive from the Mounting Bracket	3-36
3.8.2	Setting the SCSI ID of the Replacement TZK10 Tape Drive	3-37
3.9	Removing a TLZ06 Tape Drive	3-38
3.9.1	Separating the TLZ06 Tape Drive from the Mounting Bracket	3-41
3.9.2	Setting the SCSI ID and Option Switches of the Replacement TLZ06 Tape Drive	3-42
3.10	Removing an RRD42 CD-ROM Drive	3-43
3.10.1	Separating the RRD42 CD-ROM Drive from the Mounting Bracket	3-46
3.10.2	Setting the SCSI ID on the Replacement RRD42 CD-ROM Drive	3-47

3.11	Removing the Upper and Lower Drive-Mounting Shelf Combination	3-48
3.12	Removing the SCSI Cable	3-51
3.13	Removing the DSW42 Synchronous Communications Option ...	3-54
3.13.1	Removing the DSW42 Logic Board	3-55
3.13.2	Removing the DSW42 Input/Output Cable	3-56
3.13.3	Removing the DSW42 Input/Output Module	3-57
3.14	Removing the DHW42 Asynchronous Communications Option	3-58
3.14.1	Removing the DHW42 Logic Board	3-59
3.14.2	Removing the DHW42 Input/Output Cable	3-60
3.14.3	Removing the DHW42 Input/Output Module	3-61
3.15	Removing the CPU Module	3-63
3.16	Replacing the CPU Module	3-67
3.17	Removing the Power Supply Unit	3-70

A Pin Specifications for the Ports on the BA42-B System

B Recommended Spare Parts List

Glossary

Index

Figures

1-1	BA42-B Enclosure	1-2
1-2	Controls, Indicators, Ports, and Connectors	1-4
1-3	Power Distribution	1-8
1-4	Signal Distribution	1-9
1-5	Memory Expansion Connectors on the KA45 CPU Module ..	1-12
1-6	Memory Expansion Connectors on the KA47 CPU Module ..	1-14
1-7	Memory Expansion Connectors on the KA50 CPU Module ..	1-16
1-8	Communications Options in Model 40 and Model 80 Systems	1-18
1-9	Communications Options in Model 90 Systems	1-19
1-10	Mass Storage Device Combinations in the BA42-B Enclosure	1-22
2-1	BA42-B Dimensions	2-2

2-2	System Unit and Accessory Tray Contents	2-6
2-3	Connecting the Console Terminal	2-9
2-4	Connecting the ThinWire Terminator to the System Unit . . .	2-11
2-5	Connecting the Standard Ethernet Loopback Connector to the System Unit	2-12
2-6	Connecting the Power Cord	2-14
2-7	Turning On the System Unit	2-15
3-1	Major FRUs in the BA42-B Enclosure	3-4
3-2	Removing the Enclosure Cover	3-5
3-3	Memory Module Connectors on the KA45 or KA47 CPU Module	3-7
3-4	Memory Module Connectors on the KA50 CPU Module	3-8
3-5	Removing a Memory Module	3-9
3-6	Removing RZ-Series Disk Drives from the Upper Drive-Mounting Shelf	3-11
3-7	Separating the Support Plate from the Disk Drive	3-12
3-8	Separating the Mounting Bracket from the RZ25 Disk Drive	3-14
3-9	RZ23L Disk Drive SCSI ID Jumper Wire Locations	3-15
3-10	RZ24 Disk Drive SCSI ID Jumper Wire Locations	3-16
3-11	RZ25 Disk Drive SCSI ID Jumper Wire Locations	3-17
3-12	RZ26 Disk Drive SCSI ID Jumper Wire Locations	3-18
3-13	RZ35 Disk Drive SCSI ID Jumper Wire Locations	3-19
3-14	Removing the Upper Drive-Mounting Shelf	3-21
3-15	Removing an RZ-Series Disk Drive from the Lower Drive-Mounting Shelf	3-23
3-16	Removing the RX26 Diskette Drive Assembly	3-25
3-17	Removing the RX26 FDI/SCSI Board	3-26
3-18	Separating the Mounting Bracket from the RX26 Diskette Drive	3-27
3-19	Location of the SCSI ID Switches on the RX26 FDI/SCSI Board	3-28
3-20	How to Reach the SCSI ID Switches on the RX26 FDI/SCSI Board	3-29
3-21	Removing a TZ30 Tape Drive	3-30
3-22	Separating the Mounting Bracket from the TZ30 Tape Drive	3-32
3-23	TZ30 SCSI ID Switch Locations	3-33

3-24	Removing the TZK10 Tape Drive	3-35
3-25	Separating the Mounting Bracket from the TZK10 Tape Drive	3-36
3-26	Locations of the SCSI ID Jumper Wires on the TZK10 Tape Drive	3-38
3-27	Removing the TLZ06 Tape Drive	3-40
3-28	Separating the Mounting Bracket from the TLZ06 Tape Drive	3-41
3-29	Locations of the SCSI ID and Option Switches on the TLZ06 Tape Drive	3-43
3-30	Removing the RRD42 CD-ROM Drive	3-45
3-31	Separating the Mounting Bracket from the RRD42 CD-ROM Drive	3-46
3-32	RRD42 SCSI ID Jumper Wire Locations	3-48
3-33	Removing the Upper and Lower Drive-Mounting Shelf Combination	3-50
3-34	Disconnecting the SCSI Cable	3-51
3-35	Separating the Upper Drive-Mounting Shelf from the Lower Drive-Mounting Shelf	3-52
3-36	Releasing the SCSI Cable Clamp (Model 40 and Model 80 Only)	3-53
3-37	Releasing the SCSI Cable (Model 90 Only)	3-54
3-38	Removing the DSW42 Logic Board	3-56
3-39	Removing the DSW42 Input/Output Cable	3-57
3-40	Removing the DSW42 Input/Output Module	3-58
3-41	Removing the DHW42 Logic Board	3-60
3-42	Removing the DHW42 Input/Output Cable	3-61
3-43	Removing the DHW42 Input/Output Module	3-62
3-44	Disconnecting the Cables from the CPU Module	3-64
3-45	Removing the CPU Module	3-66
3-46	Location and Orientation of the Ethernet ID ROM for Models 40 and 80	3-68
3-47	Location and Orientation of the Ethernet ID ROM for Model 90	3-69
3-48	Removing the Power Supply Unit	3-71
A-1	Pin Specifications for the Ports on the BA42-B System	A-2

Tables

1-1	Functions of the Controls, Indicators, Ports, and Connectors	1-5
1-2	Power Supply Unit dc Outputs	1-7
1-3	Memory Configurations for the Model 40 System	1-11
1-5	Memory Configurations for the Model 80 System	1-13
1-5	Memory Configurations for the Model 90 System	1-15
1-6	BA42-B Communications Options	1-17
1-7	DSW42-AA Communications Interface Support	1-17
1-8	BA42-B Mass Storage Devices	1-20
2-1	Temperature, Humidity, and Altitude Ranges	2-4
2-2	BA42-B Electrical Requirements	2-5
2-3	Terminal Settings	2-7
3-1	Major FRUs in the BA42-B Enclosure	3-3
A-1	Asynchronous Port A and Port B Pin Specifications for the Eight-Data and 16-Data Line Options	A-3
A-2	Asynchronous Port A and Port B Pin Specifications for the Eight-Modem Control Line Option	A-4
A-3	Pin Specifications for Synchronous Port 0 and Port 1	A-6
A-4	Pin Specifications for the External SCSI Connector	A-9
B-1	Recommended Spare Parts	B-1

Preface

This manual provides the information that you need to maintain the BA42-B enclosure. It contains physical information about the enclosure, installation information, and procedures for replacing field replaceable units (FRUs).

Audience

This manual is for Digital™ Services personnel who provide support and maintenance for systems that use this enclosure. It is also for customers who have a self-maintenance agreement with Digital Equipment Corporation. Readers of this manual must have experience of replacing hardware components.

Structure of This Manual

This manual is divided into three chapters, two appendixes, a glossary, and an index:

- Chapter 1 provides an overview of the system enclosure and describes the controls, mass storage areas and capacity, signal distribution, power distribution, input and output connections, and configuration guidelines.
- Chapter 2 provides site preparation information and describes how to install the systems that use the enclosure.
- Chapter 3 provides instructions on removing and replacing FRUs.

- Appendix A gives the pin specifications for the ports on the back of the system unit.
- Appendix B gives a list of the recommended spare parts.

Associated Documents

The following documents contain additional maintenance information for BA42-B enclosure systems:

- *Guide to MicroVAX™ 3100 Platform Maintenance Information Kit, EK-A0512-MG*
- *KA45 CPU System Maintenance, EK-A0513-MG*
- *KA47 CPU System Maintenance, EK-A0514-MG*
- *KA50 CPU System Maintenance, EK-Axxxx-MG*
- *CPU Reference Information, EK-A0574-HR*
- *Options, EK-A0519-MG*

Note

Figures in this document apply to Models 40, 80, and 90 unless stated otherwise.

Related Documents

The following documents contain more information about MicroVAX 3100 platform systems:

- *MicroVAX 3100 Model 40 and Model 80 Cover Letter, EK-A0517-CL*
- *MicroVAX 3100 Model 40 and Model 80 Installation Information, EK-A0523-IN*
- *MicroVAX 3100 Model 40 and Model 80 Operator Information, EK-A0524-UG*
- *MicroVAX 3100 Model 40 and Model 80 Customer Technical Information, EK-A0525-TD*
- *MicroVAX 3100 Model 40 and Model 80 Troubleshooting and Diagnostic Information, EK-A0518-TM*
- *MicroVAX 3100 Model 90 Cover Letter, EK-A0517-CL*

- *MicroVAX 3100 Model 90 Installation Information, EK-A0523-IN*
- *MicroVAX 3100 Model 90 Operator Information, EK-A0524-UG*
- *MicroVAX 3100 Model 90 Customer Technical Information, EK-A0525-TD*
- *MicroVAX 3100 Model 90 Troubleshooting and Diagnostic Information, EK-A0518-TM*
- *VMS Factory Installed Software User Guide, EK-A0377-UG*

Conventions

The following conventions are used in this manual:

Convention	Description
Ctrl/ <i>x</i>	Ctrl/ <i>x</i> indicates that you hold down the Ctrl key while you press another key or mouse button (indicated here by <i>x</i>).
<i>x</i>	A lowercase italic <i>x</i> indicates the generic use of a letter. For example, <i>xxx</i> indicates any combination of three alphabetic characters.
<i>italic type</i>	Italic type emphasizes important information, indicates variables, and indicates the complete titles of manuals.
boldface type	Boldface type in examples indicates user input. Boldface type in text indicates the first instance of terms defined either in the text, in the glossary, or both.
<i>nn nnn.nnn nn</i>	A space character separates groups of 3 digits in numerals with 5 or more digits. For example, <i>10 000</i> equals <i>ten thousand</i> .
<i>n.nn</i>	A period in numerals signals the decimal point indicator. For example, <i>1.75</i> equals <i>one and three-fourths</i> .
Note	A note contains information of special importance to the reader.
Caution	A caution contains information to prevent damage to the equipment.

1

Enclosure Description


This chapter describes the BA42-B enclosure. It gives information on the following:

- Mass storage device areas
- Controls, indicators, ports, and connectors
- Power and signal distribution
- Air circulation
- Configuration guidelines

The BA42-B enclosure houses the system unit of the MicroVAX 3100 Model 40, Model 80, and Model 90 systems. It is a desktop style enclosure (see Figure 1-1).

Enclosure Description

Figure 1-1 BA42-B Enclosure



RE_EN06213A_91

Enclosure Description

1.1 Mass Storage Device Areas


The BA42-B enclosure can contain 3.5 inch (13.5 cm) and 5.25 inch (20.25 cm) half-height mass storage devices. These mass storage devices are mounted on two drive-mounting shelves. The upper drive-mounting shelf can contain one, two, or three disk drives. The lower drive-mounting shelf can contain one or two devices, that is, disk drives or removable media devices. See Section 1.5.3 for information about mass storage device combinations and orientation.

1.2 Controls, Indicators, Ports, and Connectors

The power OK indicator (POK) is on the front of the BA42-B enclosure. Figure 1-2 shows the controls, indicators, ports, and connectors on the BA42-B enclosure. Table 1-1 describes the functions of the controls, indicators, ports, and connectors.

Enclosure Description

Figure 1–2 Controls, Indicators, Ports, and Connectors



RE_EN06214A_91

Enclosure Description

Table 1–1 Functions of the Controls, Indicators, Ports, and Connectors

Component	Description
On/Off switch	Applies and stops the power to the system unit as follows: <ul style="list-style-type: none">• On (I) —Applies the ac power to the system unit• Off (O) —Stops the ac power to the system unit
System ac power socket	A socket for the ac power input.
SCSI ¹ port	A port that allows you to connect external SCSI devices.
Synchronous communications ports (0,1) ²	Two ports that allow you to connect devices that have synchronous communications support.
Asynchronous communications ports (A,B) ²	One or two ports that provide one of the following asynchronous communications expansion options: <ul style="list-style-type: none">• Eight DEC423 compatible asynchronous ports• Sixteen DEC423 compatible asynchronous ports• Eight EIA-232 compatible modem ports
MMJ ³ port 0	DEC423 compatible asynchronous port. On models 40 and 80, this port is the primary console port. On model 90, this is the standard terminal port.
MMJ port 1	DEC423 compatible asynchronous port.
MMJ port 3	DEC423 compatible asynchronous port. For models 48 and 80, this port functions as an alternate console port when the break/enable switch is set in the up position when you turn on the system unit. For model 90, this port is the primary console port.
Asynchronous modem control port (2)	EIA-232 compatible asynchronous port with modem control.
Halt push button	A momentary-contact push button that puts the system in console mode.

¹Small computer system interface (SCSI).

²Optional ports that depend on the system configuration.

³Modified modular jack (MMJ).

(continued on next page)

Enclosure Description

Table 1–1 (Cont.) Functions of the Controls, Indicators, Ports, and Connectors

Component	Description
Break/enable switch ⁴	<p>A two-position switch that determines the function of MMJ port 3 as follows:</p> <ul style="list-style-type: none">• Up position—On models 40 and 80, MMJ port 3 functions as a console port. On model 90, this enables the Break key. In this state, you can press the Break key on the keyboard of a terminal connected to MMJ port 3 to put the system in console mode.• Down position—On models 40 and 80, MMJ port 3 functions as a normal communications port and MMJ port 0 functions as a console port. On model 90, this disables the Break key.
Break/enable LED	<p>A LED⁵ indicates the position of the Break Enable switch as follows:</p> <ul style="list-style-type: none">• On—On models 40 and 80, MMJ port 3 functions as a console port. On model 90, this enables the Break key. In this state, you can press the Break key on the keyboard of a terminal connected to MMJ port 3 to put the system in console mode.• Off—On models 40 and 80, MMJ port 3 functions as a normal communications port and MMJ port 0 functions as a console port. On model 90, this disables the Break key.
LED display	<p>A set of eight LEDs that provides power-up and self-test diagnostic code information. This is useful for fault diagnosis when the console terminal is not functioning. LEDs five and six on not used for the model 90.</p>
Standard Ethernet port	<p>A port that allows you to connect the system to a standard Ethernet network.</p>
Ethernet switch	<p>A two-position switch that determines the type of Ethernet that the system uses as follows:</p> <ul style="list-style-type: none">• Left position—selects the standard Ethernet type• Right position—selects the ThinWire™ Ethernet type

⁴The system recognizes the position of this switch only when you turn on the power.

⁵Light emitting diode (LED).

(continued on next page)

Enclosure Description

Table 1–1 (Cont.) Functions of the Controls, Indicators, Ports, and Connectors

Component	Description
ThinWire Ethernet port	A port that allows you to connect the system to a ThinWire Ethernet network.

1.3 Power and Signal Distribution

The power supply unit (30-35042-01) provides power to all the units in the enclosure. It accepts alternating current (ac) input voltage in the ranges 110 V ac to 120 V ac (88 V rms¹ to 132 V rms) and 220 V ac to 240 V ac (176 V rms to 264 V rms).

The regulators in the power supply unit maintain the correct direct current (dc) output voltages, which are independent of the fluctuations in the ac input power. The power supply unit can provide a continuous power output of 166 watts (W). The power supply unit has two internal, variable speed, automatically adjusting fans that cool the unit while it operates. Table 1–2 gives the current specifications of the dc circuits.

Table 1–2 Power Supply Unit dc Outputs

Voltage (dc)	Output Current Range in Amperes (dc)	
	Minimum (A ¹)	Maximum (A)
+5.1	3.8	15.0
+12.1	0.18	7.1
-12.0	0.3	1.0
-9.0	0.0	0.2
+3.3	0.0	3.5

¹Amperes (A).

The power supply unit (30-35042-01) has the following output connectors:

- A flying lead connector that provides the dc power to the central processing unit (CPU) module
- One connector on the side of the power supply unit that provides the dc power to the devices on the upper drive-mounting shelf


¹ Root mean square.

Enclosure Description

- One connector on the side of the power supply unit that provides the dc power to the devices on the lower drive-mounting shelf
- One connector that provides a 3.3 V dc output (Model 80 systems only).

Figure 1–3 shows the distribution of power in the BA42-B enclosure.

Figure 1–3 Power Distribution




Note: RZ2* denotes RZ23L, RZ24, RZ24L, RZ25, or RZ26 disk drives.

RE_EN06215M_91

Enclosure Description

Appendix A provides information on the pin specifications for the connectors. The CPU module is the main source for signal distribution in a BA42-B enclosure system. The SCSI cable is connected to the CPU module. Each of the other connectors on the SCSI cable has a pull-tab. Use the pull-tab to disconnect the cable from a SCSI device. Each pull-tab has a number that identifies the drive to which the SCSI cable connector is connected (see Figure 1-4).

Figure 1-4 Signal Distribution



Note: RZ2* denotes RZ23L, RZ24, RZ24L, RZ25, or RZ26 disk drives.

RE_EN06216M_91

Enclosure Description

1.4 Air Circulation

The power supply unit (30-35042-01) contains two fans. These fans provide the air circulation for the enclosure. The fans adjust their speed automatically as the temperature of the system unit changes. The air intake is on the right side of the BA42-B enclosure (when viewed from the front), and the air exhaust is on the left side. A typical value of airflow is 0.0104 cubic meters per second (m^3/sec) (22 cubic feet per minute [ft^3/min]).

1.5 Configuration Guidelines

The combination of memory, communications options, and internal mass storage devices determines the configuration of a system. See the *KA45 CPU System Maintenance* manual, the *KA47 CPU System Maintenance* manual, or the *KA50 CPU System Maintenance* manual for a list of the external mass storage devices that a MicroVAX 3100 platform system supports.

1.5.1 Memory

The MicroVAX 3100 Model 40, Model 80, and Model 90 systems have different memory configurations.

1.5.1.1 Model 40 Memory Configurations

In the Model 40, the basic system memory is 8M bytes. This memory is permanently fixed to the CPU module. You can expand the memory in the system in 8M-byte increments by adding MS44-BA or MS44L-BA memory options. Each MS44-BA memory option consists of two MS44-AA (4M-byte) memory modules. Each MS44L-BA memory option consists of two MS44L-AA (4M-byte) memory modules. Table 1-3 lists the memory configurations for a Model 40 system. Figure 1-5 shows the location of the memory expansion connectors on the KA45 CPU module.

Enclosure Description

Table 1–3 Memory Configurations for the Model 40 System


Total Memory (bytes)	Onboard Memory (bytes)	Increment 1		Increment 2		Increment 3	
		1H ¹	1L	2H	2L	3H	3L
8M	8M						
16M	8M	MS44-AA ²	MS44-AA				
24M	8M	MS44-AA	MS44-AA	MS44-AA	MS44-AA		
32M	8M	MS44-AA	MS44-AA	MS44-AA	MS44-AA	MS44-AA	MS44-AA

¹1H, 1L, 2H, 2L, 3H, 3L are connector identifiers (see Figure 1–5).

²The MS44-AA memory module is a 4M-byte memory module. Each MS44L-AA memory option consists of two MS44L-AA memory modules. You can use MS44L-AA memory modules in place of MS44-AA memory modules.

Enclosure Description

Figure 1-5 Memory Expansion Connectors on the KA45 CPU Module



RE_EN06217A_91

1.5.1.2 Model 80 Memory Configurations

In the Model 80, the basic system memory is 8M bytes. This memory is contained on two MS44-AA or MS44L-AA modules installed on the KA47 CPU module. You can expand the system memory in 8M-byte or 32M-byte increments by adding MS44-BA, MS44L-BA or MS44-DA memory options. An MS44-BA memory option consists of two MS44-AA (4M-byte) memory modules. An MS44L-BA memory option consists of two MS44L-AA (4M-byte) memory modules. An MS44-DA memory option consists of two MS44-CA (16M-byte) memory modules. Table 1-5 lists the memory configurations for Model 80 systems. Figure 1-6 shows the locations of the memory expansion connectors on the KA47 CPU module.

Enclosure Description

Table 1–5 Memory Configurations for the Model 80 System

Total Memory (bytes)	Increment 1 ¹		Increment 2		Increment 3	
	1H ²	1L	2H	2L	3H	3L
8M	MS44-AA ³	MS44-AA				
16M	MS44-AA	MS44-AA	MS44-AA	MS44-AA		
24M	MS44-AA	MS44-AA	MS44-AA	MS44-AA	MS44-AA	MS44-AA
40M	MS44-AA	MS44-AA	MS44-CA ⁴	MS44-CA		
48M	MS44-AA	MS44-AA	MS44-AA	MS44-AA	MS44-CA	MS44-CA
72M	MS44-AA	MS44-AA	MS44-CA	MS44-CA	MS44-CA	MS44-CA

¹Basic system memory.


²1H, 1L, 2H, 2L, 3H, 3L are connector identifiers (see Figure 1–6).

³The MS44-AA memory module is a 4M-byte memory module. The MS44-BA memory option consists of two MS44-AA memory modules. You can use MS44L-AA memory modules in place of MS44-AA memory modules.

⁴The MS44-CA memory module is a 16M-byte memory module. The MS44-DA memory option consists of two MS44-CA memory modules.

Enclosure Description

Figure 1–6 Memory Expansion Connectors on the KA47 CPU Module



RE_EN06218A_91

1.5.1.3 Model 90 Memory Configurations

In the Model 90, the basic system memory is 16M bytes. This memory is contained on four MS44L-AA modules installed on the KA50 CPU module. You can expand the system memory in 16M-byte or 64M-byte increments by adding MS44L-BC or MS44-DC memory options. An MS44L-BC memory option consists of MS44L-AA (4M-byte) memory modules. An MS44-DC memory option consists of four MS44-CA (16M-byte) memory modules. Table 1–5 lists the memory configurations for Model 90 systems. Figure 1–6 shows the locations of the memory expansion connectors on the KA50 CPU module.

Enclosure Description

Table 1–5 Memory Configurations for the Model 90 System


Total Memory (bytes)	Increment 1¹ (0A + 0B + 0C + 0D)²	Increment 2 (1E + 1F + 1G + 1H)²
16M	MS44L-BC	
32M	MS44L-BC	MS44L-BC
64M	MS44-DC	
80M	MS44-DC	MS44L-BC
128M	MS44-DC	MS44-DC

¹Basic system memory.

²0A, 0B, 0C, 0D, 1E, 1F, 1G, and 1H are connector identifiers (see Figure 1–6).

Enclosure Description

Figure 1-7 Memory Expansion Connectors on the KA50 CPU Module



GA_EN00093A_92A

1.5.2 Communications Options

Table 1-6 lists the communications options that a BA42-B enclosure can contain.

Enclosure Description

Table 1–6 BA42-B Communications Options

Option Name	Description
Asynchronous Options	
DHW42-AA	Provides eight DEC423 asynchronous lines
DHW42-BA	Provides 16 DEC423 asynchronous lines
DHW42-CA	Provides eight EIA-232 asynchronous modem lines
DHW42-UP	Eight to 16 DEC423 asynchronous line upgrade
Synchronous Options	
DSW42-AA ¹	Provides two EIA-232/V.24 synchronous lines

¹This option is supplied with two external cables that support the EIA-232/V.24 interface.

The DSW42-AA option also supports the communications interfaces listed in Table 1–7, but you must order the external cable separately.

Table 1–7 DSW42-AA Communications Interface Support

Communications Interface	External Cable
EIA-423/V.10	BC19E-02
EIA-422/V.11	BC19B-02

Each communications option contains three field replaceable units (FRUs) that are installed in the enclosure as follows:


- A logic board
The logic board connects directly to the CPU module.
- An input/output cable
The input/output cable connects the CPU module to the input/output module.
- An input/output module
The input/output module is a snap-fit assembly that is attached to the inside of the back panel of the BA42-B enclosure.

Enclosure Description

The communications options logic boards have different locations in the BA42-B enclosure, depending on the model number of the system, as follows:

- In Model 40 and Model 80 systems, the DHW42 logic board is located to the right of the CPU Module, with the DSW42 logic board located to its left (see Figure 1–8).
- In Model 90 systems, the DHW42 logic board is located to the left of the CPU Module, with the DSW42 logic board located to its right (see Figure 1–9).


Figure 1–8 Communications Options in Model 40 and Model 80 Systems



RE_EN06219A_91

Enclosure Description

Figure 1–9 Communications Options in Model 90 Systems



Enclosure Description

1.5.3 Mass Storage Devices

Table 1–8 lists the mass storage devices that the BA42-B enclosure can contain.

Table 1–8 BA42-B Mass Storage Devices

Option Name	Description	Size ¹ (in)	Capacity
RZ23L	Disk drive	3.5	120M bytes
RZ24	Disk drive	3.5	209M bytes
RZ24L	Disk drive	3.5	245M bytes
RZ25	Disk drive	3.5	400M bytes
RZ26	Disk drive	3.5	1.05 Gigabytes (G bytes)
RZ35	Disk drive	3.5	852M bytes
TZ30 ²	Tape drive	5.25	95M byte cartridge
TZK10 ²	Tape drive	5.25	Range of cartridges ³
TLZ06 ²	Tape drive	5.25	Range of cassettes ⁴
RX26 ²	Diskette drive	3.5	Range of diskettes ⁵
RRD42 ²	CD-ROM ⁵ drive	5.25	600M byte CD-ROM

¹Size of half-height device.

²Removable media device.

³Supports 320M byte and 525M byte cartridges.

⁴Supports 60 metre (m) and 90 m cassettes

⁵Supports 1.4M byte and 2.8M byte diskettes.

The BA42-B enclosure has two drive-mounting shelves for mass storage devices as follows:

- Upper drive-mounting shelf
The upper drive-mounting shelf can contain one, two, or three disk drives.
- Lower drive-mounting shelf
The lower drive-mounting shelf can contain one or two devices. These devices are either disk drives or removable media devices.


Enclosure Description

Figure 1-10 shows the combinations of mass storage devices in a BA42-B enclosure.


Enclosure Description

Figure 1–10 Mass Storage Device Combinations in the BA42-B Enclosure

Upper Drive-Mounting Shelf



Upper Drive-Mounting Shelf



Left-hand compartment

Right-hand compartment

Note: RZ* denotes RZ23L, RZ24, RZ24L, RZ25 or RZ26 disk drives.

GA_EN00187D_92A

2

Installation

This chapter describes how to install a BA42-B system. It gives information on the following:

- Preparing the site
- Unpacking the system
- Installing a BA42-B system

2.1 Preparing the Site

Before you unpack the BA42-B system, verify the physical, environmental, and electrical requirements described in this section.

2.1.1 Dimensions


Figure 2–1 shows the dimensions of the BA42-B enclosure.

Caution

The container and enclosure together typically weigh 20.50 kilograms (kg) (45 pounds [lb]). Two people are required to handle the container.

Installation

Figure 2-1 BA42-B Dimensions



RE_EN06221A_91

The dimensions of the container are as follows:

- Height = 35.3 cm (14.0 inches)
- Width = 61.1 cm (24.0 inches)
- Depth = 51.0 cm (20.0 inches)

2.1.2 Additional Equipment

When you are installing additional equipment, follow these guidelines:

- Make sure that there is sufficient space for the terminals and other peripheral equipment.
- Make sure that you keep the mass storage devices in an area that has the same temperature and humidity as the computer area (see Table 2-1).
- When you plan the cable routing for multiple-terminal systems, consider factors such as safety, convenience, future expansion, and cost. Label and install the cables before you install the system.

2.1.3 Operating Environment

Computer systems in office areas are subject to electrostatic discharge (ESD), temperature changes, and humidity. To install the system in the correct environment, follow these guidelines:

- Install the system in a well-ventilated area where the temperature and humidity ranges listed in Table 2–1 are maintained during the year.
- Do not place a system near heating or cooling devices, large windows, or doors that open to the outside. Rapid changes of temperature can affect the performance of the system.
- Place the system in an area where the air contains a minimum of dust and other abrasive contaminants.

2.1.4 Electrostatic Discharge

ESD can cause system failures and loss of data. To minimize the build up of static electricity, follow these guidelines:

- Maintain a relative humidity level of at least 40%.
- Place the system away from busy corridors.
- Carpet in the computer area is not recommended. However, if you want to use carpet, antistatic carpet is recommended. When carpet is already in use, put an antistatic mat under the system.

2.1.5 Heat Dissipation

The heat dissipated by a BA42-B enclosure system depends on the model number of the system, but is typically 410 British thermal units/hour (Btu/h).

2.1.6 Temperature, Humidity, and Altitude Ranges

Table 2–1 gives the operating, nonoperating, and storage ranges for the temperature, humidity, and altitude for BA42-B enclosure systems.

Installation

Table 2-1 Temperature, Humidity, and Altitude Ranges

Parameter	Operating Range¹	Nonoperating Range	Storage Range
Temperature	10°C to 40°C (50°F to 104°F)	-40°C to 66°C (-40°F to 151°F)	5°C to 50°C (41°F to 122°F)
Relative humidity ²	10% to 90%	10% to 95% ²	10% to 95%
Altitude	2400 m maximum (8000 ft maximum)	4900 m maximum (16 000 ft maximum)	
Rate of change of temperature	11°C per hour maximum (20°F per hour maximum)		

¹For operation above sea level, decrease the operating temperature by 1.8°C per 1000 m (or 1°F per 1000 ft).

²At a temperature of 66°C.

2.1.7 Electrical Requirements

The power source to which the system connects must be capable of providing power to the system unit and any other additional equipment, such as local terminals and expansion boxes. Digital™ recommends that each system operates in a dedicated power circuit. Additional power equipment may be required to avoid power interruptions. Table 2–2 lists the electrical requirements of systems in BA42-B enclosures. The power supply unit in the system is autosensing. You do not have to select the input voltage.

Table 2–2 BA42-B Electrical Requirements

Parameter	Values
Nominal voltages	110 V ac or 220 V ac
Voltage ranges	100 V ac to 120 V ac (88 V rms ¹ to 132 V rms) and 220 V ac to 240 V ac (176 V rms to 264 V rms)
Power source phase	Single
Nominal frequencies	50 Hz ² or 60 Hz
Frequency range	47 Hz to 63 Hz
Maximum running current	1.2 A for 110 V ac systems and 0.6 A for 220 V ac systems
Steady state current	1.0 A for 110 V ac systems and 0.5 A for 220 V ac systems
Maximum inrush current	32 A
Maximum power consumption	120 W

¹Root mean square (rms).

²Hertz (Hz).

2.2 Unpacking the System


Open the container. Remove the box and the accessory tray. The box contains the system unit. The accessory tray contains the following:

- *Customer Hardware Information Kit*
- *VMS Factory Installed Software User Guide*
- Software licenses
- Power cord
- Other accessories

Installation

Expansion boxes are supplied in separate containers.

Figure 2–2 System Unit and Accessory Tray Contents



RE_EN06222A_91

Depending on the system configuration, the contents of the container may differ from the items shown in Figure 2–2. When unpacking the system, do the following:

1. Check the contents of the container against the packing slip.
2. Store the unused parts for future use. Depending on how you set up the system, you may not use all the components supplied with the system.

Always repack the system unit in its original packing material when moving or relocating the system. This precaution protects the system from damage.

2.3 Installing the BA42-B System

Install the BA42-B enclosure according to the instructions in the following subsections.

2.3.1 Placing the BA42-B Enclosure

After you unpack the system, move the BA42-B enclosure to the location from which it will operate. Place the enclosure so that it satisfies the following space requirements:

- Allow 5 cm (2 inches approximately) of clearance on each side of the enclosure for ventilation.
- Allow 10 cm (4 inches approximately) of clearance on the back of the enclosure for the connection of cables.
- Allow 20 cm (8 inches approximately) of clearance on the front of the enclosure so that you can reach the removable media devices, depending on the system configuration.

2.3.2 Identifying the Ports and Connectors on the System Unit

Figure 1–2 shows the ports and connectors in a BA42-B enclosure system. Section 1.2 describes the functions of the controls, indicators, ports, and connectors in a BA42-B enclosure system.

2.3.3 Connecting the Console Terminal

To connect a console terminal to a BA42-B enclosure, follow these steps:

1. Make sure that the on/off switch on the terminal is in the off position.
2. Set the communication parameters of the terminal (see Table 2–3).

Table 2–3 Terminal Settings

Feature	Setting
Terminal mode	VTnnn-7bit
Transmit speed	9600 baud
Receive speed	receive = transmit
Character format	8 bits, no parity
Stop bits	1
Comm1 port	DEC-423 (data-leads-only)

Installation

See the terminal documentation if you want more information on setting up the terminal.

Note

If you connect the terminal cable to one of the MMJ ports on the back of a VT3xx terminal, you must set the port so that it can operate as a DEC423 port. See the terminal documentation for more information.


3. Connect the terminal cable supplied with the system (see Figure 2-2) to MMJ port 3 on the back of the system unit (see Figure 2-3). Connect the other end of the console cable to a DEC423 port on the terminal. You may remove the label covering MMJ ports 0 and 1.
4. If the terminal has EIA-232 ports only, connect the EIA-232 to DEC423 adapter to the EIA-232 port on the terminal. Then connect the terminal cable to the EIA-232 to DEC423 adapter.

Note

Some terminal cables have an earth drain wire. You must connect this earth drain wire to the grounding pillar above MMJ port 1, using the screw provided with the cable.

Installation

Figure 2-3 Connecting the Console Terminal



GA_EN00146A_92A

Installation

2.3.4 Connecting the ThinWire Terminator or Loopback Connector

You can connect BA42-B systems to either a ThinWire Ethernet network or to a standard Ethernet network. To test the Ethernet circuitry in the system unit before you connect to a network, install either the ThinWire terminator or the standard Ethernet loopback connector.

The ThinWire terminator and the standard Ethernet loopback connector are supplied with BA42-B systems (see Figure 2–2). The ThinWire terminator consists of a T-connector and two terminators. The standard Ethernet loopback connector is a single unit.

You choose the network type using the Ethernet switch on the back of the system unit (see Figure 1–2). The switch settings for the network types are as follows:


- Left position—standard Ethernet
- Right position—ThinWire Ethernet

When you want to use a ThinWire Ethernet network, follow these steps:

1. Set the Ethernet switch to the right position.
2. To form a ThinWire terminator, connect the two terminators (see Figure 2–4) to the T-connector.
3. Connect the ThinWire terminator to the ThinWire Ethernet port on the back of the system unit turning the barrel connector clockwise until it locks (see Figure 2–4).

Installation

Figure 2-4 Connecting the ThinWire Terminator to the System Unit




GA_EN00147A_92A

Installation

If you want to use a standard Ethernet network, follow these steps:

1. Set the Ethernet switch to the left position.
2. Connect the standard Ethernet loopback connector to the standard Ethernet port on the back of the system unit (see Figure 2-5).

Figure 2-5 Connecting the Standard Ethernet Loopback Connector to the System Unit



GA_EN00148A_92A


2.3.5 Connecting the System Unit Power Cord

A BA42-B enclosure system accepts 100 V ac to 120 V ac at 50 Hz or 60 Hz, or 220 V ac to 240 V ac at 50 Hz or 60 Hz. The power supply unit is self-sensing. You do not have to select the input voltage. To connect the system unit power cord, follow these steps:

1. Set the on/off switch on the back of the system unit to the off (O) position.
2. Connect the power cord, supplied with the system (see Figure 2-2), to the ac power socket on the back of the system unit (see Figure 2-6).
3. Connect the other end of the power cord to a grounded power outlet.

Installation

Figure 2-6 Connecting the Power Cord



GA_EN00149A_92A


2.3.6 Turning On the System

To turn on the system, follow these steps:

1. Set the on/off switch on the terminal to the on position.
2. Set the on/off switch on the system unit to the on (|) position (see Figure 2-7).

Figure 2-7 Turning On the System Unit

On/Off Switch



GA_EN00150A_92A

See the *KA45 CPU System Maintenance* manual, the *KA47 CPU System Maintenance* manual, or the *KA47 CPU System Maintenance* manual for information about the self-tests that run when you turn on the system.

3

Removing and Replacing FRUs

This chapter describes how to remove and replace the FRUs in the BA42-B enclosure. It gives information on the following:

- Removing the enclosure cover
- Removing an MS44 or MS44L memory module
- Removing an RZ-series disk drive from the upper drive-mounting shelf
- Removing the upper drive-mounting shelf
- Removing an RZ-series disk drive from the lower drive-mounting shelf
- Removing an RX26 diskette drive assembly
- Removing a TZ30 tape drive
- Removing a TZK10 tape drive
- Removing a TLZ06 tape drive
- Removing an RRD42 CD-ROM drive
- Removing the upper and lower drive-mounting shelf combination
- Removing the SCSI cable
- Removing a DSW42 synchronous communications option
- Removing a DHW42 asynchronous communications option
- Removing the CPU module
- Replacing the CPU module
- Removing the power supply unit

Note

Unless otherwise specified, you can replace an FRU by reversing the steps described in the removal procedure.

Removing and Replacing FRUs

Table 3–1 lists the major FRUs in the BA42-B enclosure. It also gives the order numbers for the FRUs and a reference to a section in this chapter that gives information on how to replace the FRU. See the *Options* manual for more information about options. Appendix B gives a complete list of the spare parts for the BA42-B enclosure. Figure 3–1 shows the locations of the major FRUs in the BA42-B enclosure.

Caution

- Disconnect the power supply before removing or installing FRUs.
 - Only qualified personnel should remove or install the FRUs.
 - Static electricity can damage integrated circuits. Wear a wrist strap and place an antistatic mat under the system unit when working with the internal parts of the system unit.
-

You must have the following tools to replace the FRUs in a MicroVAX 3100 platform system:

- A number 1, Philips screwdriver
- A flat screwdriver

Removing and Replacing FRUs

Table 3–1 Major FRUs in the BA42-B Enclosure

FRU	Order Numbers	Section
Memory module	MS44-AA, MS44L-AA, MS44-CA	3.2
Disk drive	RZ23L-E	3.3, 3.5
Disk drive	RZ24-E	3.3, 3.5
Disk drive	RZ24L-E	3.3, 3.5
Disk drive	RZ25-E	3.3, 3.5
Disk drive	RZ26-E	3.3, 3.5
Disk drive	RZ35-E	3.3, 3.5
Diskette drive	RX26-AA	3.6
Tape drive	TZ30-AX	3.7
Tape drive	TZK10-AA	3.8
Tape drive	TLZ06-AA	3.9
CD-ROM drive	RRD42-AA	3.10
Synchronous communications option	DSW42-AA	3.13
Asynchronous communications option	DHW42-AA, -BA, -CA	3.14
KA45 CPU module ¹	54-20654-01	3.15
KA47 CPU module ²	54-20652-01	3.15
KA50 CPU module ³	54-21797-01	3.15
Power supply unit	30-35042-01	3.17


¹Model 40 CPU module only

²Model 80 CPU module only

³Model 90 CPU module only

Removing and Replacing FRUs

Figure 3-1 Major FRUs in the BA42-B Enclosure



GA_EN00095A_92A


Removing and Replacing FRUs

3.1 Removing the Enclosure Cover

To remove the enclosure cover, follow these steps:

1. Set the on/off switch on the system unit to the off (O) position.
2. Disconnect the cables, loopback connectors, and terminators that are connected to the system unit.
3. Loosen the two captive screws (12-30338-05) on the back of the system unit (see Figure 3–2).
4. Slide the cover forward and lift it up from the system unit.

Figure 3–2 Removing the Enclosure Cover



RE_EN06230A_91

Removing and Replacing FRUs

3.2 Removing an MS44 or MS44L Memory Module

To remove a memory module, follow these steps:

1. Remove the enclosure cover (see Section 3.1).

Caution

Static electricity can damage integrated circuits. Wear a wrist strap and place an antistatic mat under the system unit when working with the internal parts of the system unit.


2. Locate the faulty memory module. Figure 3–3 shows the location of the memory module connectors on the KA45 or KA47 CPU module. Figure 3–4 shows the location of the memory module connectors on the KA50 CPU module.

Note

- Note the position of the faulty memory module on the CPU module. You must install a replacement in this position.
 - You may have to remove one or two memory modules to reach the faulty memory module. Note carefully the position of each memory module you remove.
-


Removing and Replacing FRUs

Figure 3-3 Memory Module Connectors on the KA45 or KA47 CPU Module



Removing and Replacing FRUs

Figure 3–4 Memory Module Connectors on the KA50 CPU Module




3. Push the metal board clips on the memory module connector away from the center. Tilt the memory module towards the back of the enclosure, and lift the memory module out of its connector (see Figure 3–5).

Caution

When installing a memory module, note that the connectors on the CPU module are keyed so that you cannot install the memory module with an incorrect orientation. Do not try to force a module into a connector with an incorrect orientation.

Removing and Replacing FRUs

Figure 3-5 Removing a Memory Module



RE_EN06246A_91

Removing and Replacing FRUs

3.3 Removing an RZ-Series Disk Drive from the Upper Drive-Mounting Shelf

Depending on the system configuration, the upper drive-mounting shelf can contain one, two, or three disk drives. The disk drives can be any combination of the RZ-series disk drives. The RZ-series disk drives include the following devices:

- RZ23L disk drive
- RZ24 disk drive
- RZ24L disk drive
- RZ25 disk drive
- RZ26 disk drive
- RZ35 disk drive

You can remove a disk drive from the enclosure without removing the upper drive-mounting shelf from the enclosure. To remove an RZ-series disk drive from the upper drive-mounting shelf, follow these steps:

1. Remove the enclosure cover (see Section 3.1).


Note

- You can disconnect the cables from a disk drive more easily after you remove the disk drive from the drive-mounting shelf.
 - When disconnecting cables, you must note which cables connect to which drives. On the SCSI cable, note the number on the connector pull-tab.
-

2. Press and hold the spring clip that locks the disk drive in position.
3. Push the disk drive towards the spring clip until the rubber grommets under the disk drive are released from the cutouts in the drive-mounting shelf (see Figure 3–6). Lift the disk drive up from the drive-mounting shelf and release the spring clip.

Removing and Replacing FRUs

Figure 3–6 Removing RZ-Series Disk Drives from the Upper Drive-Mounting Shelf



RE_EN06231A_91

4. Disconnect the SCSI cable from the back of the disk drive by pulling the pull-tab. Figure 1–4 shows the signal cables in the BA42-B enclosure.
5. Disconnect the power cable from the back of the disk drive. Figure 1–3 shows the power cables in the BA42-B enclosure.

3.3.1 Separating the Support Plate from an RZ23L, RZ24, or RZ24L Disk Drive


When you are replacing an RZ23L, RZ24, or RZ24L disk drive, you must remove the support plate (74-41364-01) and the rubber grommets (12-31734-01) that are attached to the faulty disk drive (RZ23L-E, RZ24-E, or RZ24L-E) and install these items on the replacement drive. The following procedure describes how to remove the support plate and rubber grommets from an RZ23L disk drive. The procedure for removing the support plate and rubber grommets from an RZ24 or RZ24L disk drive is the same. To remove the

Removing and Replacing FRUs

support plate and rubber grommets from an RZ23L disk drive, follow these steps:

1. Position the disk drive so that the bottom of the disk drive faces up.
2. Remove the four screws and attached grommets (see Figure 3–7). These screws secure the support plate to the disk drive.

Figure 3–7 Separating the Support Plate from the Disk Drive



RE_EN06451A_91

3. Remove the support plate from the disk drive.
4. Keep the four screws with the attached grommets and the support plate in a safe place. You must install them on the replacement disk drive.

Removing and Replacing FRUs


3.3.2 Separating the Mounting Bracket from an RZ25, RZ26, or RZ35 Disk Drive

When you are replacing an RZ25, RZ26, or RZ35 disk drive, you must remove the mounting bracket (74-44226-01) and the rubber grommets (12-31734-01) that are attached to the faulty disk drive and install these items on the replacement drive. The following procedure describes how to remove the mounting bracket and rubber grommets from an RZ25 disk drive. The procedure for removing the mounting bracket and rubber grommets from an RZ26 or RZ35 disk drive is the same. To remove the mounting bracket and rubber grommets from an RZ25 disk drive, follow these steps:

1. Position the disk drive so that the bottom of the disk drive faces up.
2. Remove the four screws and attached grommets (see Figure 3–8). These screws secure the mounting bracket to the disk drive.

Removing and Replacing FRUs

Figure 3–8 Separating the Mounting Bracket from the RZ25 Disk Drive



RE_EN06497C_91

3. Remove the mounting bracket from the disk drive.
4. Keep the four screws with the attached grommets and the mounting bracket in a safe place. You must install them on the replacement disk drive.

3.3.3 Setting the SCSI ID on the Replacement Disk Drive


To set the SCSI ID on a replacement disk drive, follow these steps:

1. Note the SCSI ID switch settings on the disk drive you removed. The locations of the SCSI ID jumper wires on the various types of disk drive are shown in the following figures:
 - RZ23L—see Figure 3–9

Removing and Replacing FRUs


- RZ24—see Figure 3–10
 - RZ25—see Figure 3–11
 - RZ26—see Figure 3–12
 - RZ35—see Figure 3–13
2. Set the SCSI ID switches on the replacement disk drive to the same settings as the SCSI ID switches of the disk drive you removed.

Figure 3–9 RZ23L Disk Drive SCSI ID Jumper Wire Locations




Removing and Replacing FRUs

Figure 3–10 RZ24 Disk Drive SCSI ID Jumper Wire Locations



Removing and Replacing FRUs


Figure 3–11 RZ25 Disk Drive SCSI ID Jumper Wire Locations



RE_EN06365C_91

Removing and Replacing FRUs


Figure 3–12 RZ26 Disk Drive SCSI ID Jumper Wire Locations



RE_EN06365C_91

Removing and Replacing FRUs

Figure 3–13 RZ35 Disk Drive SCSI ID Jumper Wire Locations



RE_EN06365C_91

See the *Options* manual for more information about setting the SCSI ID of the RZ-series disk drives.

3.4 Removing the Upper Drive-Mounting Shelf

To reach some of the FRUs in the BA42-B enclosure, you must remove the upper drive-mounting shelf. Depending on the system configuration, the upper drive-mounting shelf can contain one, two, or three disk drives. You can remove the upper drive-mounting shelf with the disk drives attached. To remove the upper drive-mounting shelf, follow these steps:

1. Remove the enclosure cover (see Section 3.1).

Removing and Replacing FRUs


Note

When disconnecting the cables, you must note which cables connect to which drives. On the SCSI cable, note the number on the connector pull-tab.

2. Disconnect the power cable from the disk drives on the upper drive-mounting shelf. Figure 1-3 shows the power cables in the BA42-B enclosure.
3. Disconnect the power cable from the power supply unit. Remove the power cable from the enclosure.
4. Disconnect the SCSI cables from the disk drives by pulling the pull-tabs. Figure 1-4 shows the SCSI cables in the BA42-B enclosure.
5. Loosen the three captive screws (see Figure 3-14).

Removing and Replacing FRUs

Figure 3–14 Removing the Upper Drive-Mounting Shelf



RE_EN06232A_91

6. Lift the left side of the upper drive-mounting shelf, and pull the drive-mounting shelf to the left until the tabs on the right side of the mounting shelf are clear of the cutouts in the lower drive-mounting shelf.
7. Remove the upper drive-mounting shelf from the enclosure.

3.5 Removing an RZ-Series Disk Drive from the Lower Drive-Mounting Shelf

Depending on the system configuration, RZ-series disk drives may be installed on the left side and the right side of the lower drive-mounting shelf, when viewed from the front. To remove an RZ-series disk drive from the lower drive-mounting shelf, follow these steps:

1. Remove the enclosure cover (see Section 3.1).

Removing and Replacing FRUs

2. Remove the upper drive-mounting shelf (see Section 3.4).


Note

- You can disconnect the cables from a disk drive more easily after you remove the drive from the drive-mounting shelf.
 - When disconnecting the cables, you must note which cables connect to which drives. On the SCSI cable, note the number on the connector pull-tab.
-

3. Press and hold the spring clip that locks the disk drive in position (see Figure 3–15).
4. Push the disk drive towards the spring clip until the rubber grommets under the disk drive are released from the cutouts in the drive-mounting shelf (see Figure 3–15). Lift the disk drive up from the lower drive-mounting shelf, and release the spring clip.

Removing and Replacing FRUs

Figure 3–15 Removing an RZ-Series Disk Drive from the Lower Drive-Mounting Shelf



RE_EN06233A_91

5. Disconnect the SCSI cable from the back of the disk drive by pulling the pull-tab. Figure 1–4 shows the signal cables in the BA42-B enclosure.
6. Disconnect the power cable from the back of the disk drive. Figure 1–3 shows the power cables in the BA42-B enclosure.
7. Remove the support plate from the disk drive (see Section 3.3.1).

3.6 Removing the RX26 Diskette Drive Assembly

The RX26 diskette drive assembly (when installed) is positioned on the left side or the right side of the lower drive-mounting shelf when viewed from the front. The RX26 diskette drive assembly contains three FRUs as follows:

- RX26-AA diskette drive
- RX26 FDI/SCSI board (54-20764-02)
- RX26 ribbon cable (17-00285-00)

Removing and Replacing FRUs

The following procedure describes how to remove an RX26 diskette drive assembly from the right side of the lower drive-mounting shelf. The procedure for removing the RX26 diskette drive assembly from the left side of the lower drive-mounting shelf is the same. To remove the RX26 diskette drive assembly from the BA42-B enclosure, follow these steps:

1. Remove the enclosure cover (see Section 3.1).
2. Remove the upper drive-mounting shelf (see Section 3.4).


Note

When disconnecting the cables, you must note which cables connect to which drives. On the SCSI cable, note the number on the connector pull-tab.

3. Disconnect the power cable from the back of the RX26 diskette drive. Figure 1-3 shows the power cables in the BA42-B enclosure.
4. Disconnect the power cable from the floppy diskette interface/small computer system interface (FDI/SCSI) board.
5. Disconnect the SCSI cable from the back of the FDI/SCSI board by pulling the pull-tab. Figure 1-4 shows the signal cables in the BA42-B enclosure.
6. Loosen the captive screw securing the mounting bracket to the lower drive-mounting shelf (see Figure 3-16).

Removing and Replacing FRUs

Figure 3–16 Removing the RX26 Diskette Drive Assembly



RE_EN06234A_91

7. Lift the left side of the RX26 diskette drive assembly and pull the diskette drive assembly to the left until the tabs on the right side of the mounting bracket are clear of the cutouts in the lower drive-mounting shelf.
8. Lift the RX26 diskette drive assembly out of the BA42-B enclosure.

3.6.1 Removing the RX26 FDI/SCSI Board


To remove the FDI/SCSI board from the RX26 mounting bracket, follow these steps:

1. Disconnect the ribbon cable that connects the RX26 diskette drive to the RX26 FDI/SCSI board.
2. Turn the RX26 diskette drive assembly over so that the base of the mounting bracket faces up.

Removing and Replacing FRUs

3. Press firmly on the front edge of the FDI/SCSI board with your finger. When the two holes on the front edge of the FDI/SCSI board are clear of the tabs in the RX26 mounting bracket, slide the RX26 FDI/SCSI board out of the RX26 mounting bracket (see Figure 3–17).

Figure 3–17 Removing the RX26 FDI/SCSI Board



RE_EN06235A_91


3.6.2 Separating the RX26 Diskette Drive from the Mounting Bracket

When you are installing a replacement RX26 diskette drive, you must use the mounting bracket (70-29669-01) that is attached to the faulty RX26 diskette drive (RX26-AA). To separate the RX26 diskette drive from its mounting bracket, follow these steps:

1. Remove the four screws (90-10961-03) securing the RX26 mounting bracket to the RX26 diskette drive.
2. Separate the mounting bracket from the RX26 diskette drive (see Figure 3–18).

Removing and Replacing FRUs

Figure 3–18 Separating the Mounting Bracket from the RX26 Diskette Drive



RE_EN06452A_91


3.6.3 Setting the SCSI ID on the Replacement RX26 FDI/SCSI Board

When replacing the FDI/SCSI board, you must set the SCSI ID of the replacement board to the SCSI ID of the board you remove. To set the SCSI ID on a replacement RX26 FDI/SCSI board, follow these steps:

1. Note the SCSI ID switch settings on the RX26 FDI/SCSI board you removed. Figure 3–19 shows the location of the SCSI ID switches on the FDI/SCSI board.
2. Set the SCSI ID switches on the replacement RX26 FDI/SCSI board to the same settings as the SCSI ID switches of the RX26 FDI/SCSI board you removed.

Removing and Replacing FRUs

Figure 3–19 Location of the SCSI ID Switches on the RX26 FDI/SCSI Board




RE_EN06236A_91

After you install the FDI/SCSI board and connect the RX26 ribbon cable, you can reach the SCSI ID switches through a ventilation slot in the mounting bracket (see Figure 3–20).

Removing and Replacing FRUs

Figure 3–20 How to Reach the SCSI ID Switches on the RX26 FDI/SCSI Board



Note: The SCSI ID shown is 4 (S1 is on, S2 is off, and S3 is off).

RE_EN06471A_91

3.7 Removing a TZ30 Tape Drive

The TZ30 tape drive (when installed) is on the right side of the lower drive-mounting shelf, when viewed from the front. To remove a TZ30 tape drive from the BA42-B enclosure, follow these steps:

1. Remove the enclosure cover (see Section 3.1).
2. Remove the upper drive-mounting shelf (see Section 3.4).


Removing and Replacing FRUs

Note

- You can disconnect the cables from the drive more easily after you remove the drive from the drive-mounting shelf.
 - When disconnecting the cables, you must note which cables connect to which drives. On the SCSI cable, note the number on the connector pull-tab.
-

3. Loosen the captive screw that secures the mounting bracket to the drive-mounting shelf (see Figure 3–21).

Figure 3–21 Removing a TZ30 Tape Drive



GA_EN00202A_92A

4. Lift the left side of the TZ30 tape drive. Slide the TZ30 tape drive to the left until the tabs on the right side of the mounting bracket are clear of the cutouts in the drive-mounting shelf.

Removing and Replacing FRUs

5. Disconnect the power cable from the flying lead connector of the TZ30 tape drive. Figure 1–3 shows the power cables in the BA42-B enclosure.
6. Disconnect the SCSI cable from the TZ30 tape drive by pulling the pull-tab. Figure 1–4 shows the signal cables in the BA42-B enclosure.
7. Lift the TZ30 tape drive, which has its mounting bracket attached, out of the system unit.


3.7.1 Separating the TZ30 Tape Drive from the Mounting Bracket

When you are installing a replacement TZ30 tape drive, you must use the mounting bracket (74-42115-01) that is attached to the faulty TZ30 tape drive (TZ30-AA). To separate the mounting bracket from the faulty TZ30 tape drive, follow these steps:

1. Remove the two screws (90-09984-07) from the right side of the mounting bracket (see Figure 3–22).
2. Remove one screw (90-09984-07) from the left side of the mounting bracket (see Figure 3–22).
3. Remove one screw (90-10961-03) from the bottom of the drive mounting bracket (see Figure 3–22).
4. Separate the mounting bracket from the TZ30 tape drive.

Removing and Replacing FRUs

Figure 3–22 Separating the Mounting Bracket from the TZ30 Tape Drive



GA_EN00211A_92A

5. Keep the mounting bracket and the four screws in a safe place because you must use them to install the replacement TZ30 tape drive.


3.7.2 Setting the SCSI ID on the Replacement TZ30 Tape Drive

To set the SCSI ID on the replacement TZ30 tape drive, follow these steps:

1. Note the SCSI ID switch settings on the TZ30 tape drive you removed. Figure 3–23 shows the location of the SCSI ID switches and the recommended SCSI ID for tape drives.
2. Set the SCSI ID switches on the replacement TZ30 tape drive to the same settings as the SCSI ID switches on the TZ30 tape drive you removed.

Removing and Replacing FRUs

Figure 3–23 TZ30 SCSI ID Switch Locations



Notes: 1. S1 is not used (always on).

2. The SCSI ID shown is 5 (S2 is on, S3 is off, and S4 is on).

GA_EN00203A_92A

See the *Options* manual for more information about setting the SCSI ID of the TZ30 tape drive.

3.8 Removing a TZK10 Tape Drive

The TZK10 tape drive (when installed) can be on the right side or the left side of the lower drive-mounting shelf, when viewed from the front. The following procedure describes how to remove a TZK10 tape drive from the right side of the lower drive-mounting shelf. The procedure for removing the TZK10 tape drive from the left side of the lower drive-mounting shelf is the same. To remove a TZK10 tape drive from the BA42-B enclosure, follow these steps:

1. Remove the enclosure cover (see Section 3.1).

Removing and Replacing FRUs

2. Remove the upper drive-mounting shelf (see Section 3.4).


Note

- You can disconnect the cables from the drive more easily after you remove the drive from the drive-mounting shelf.
 - When you disconnect the cables, note which cables connect to which drives. On the SCSI cable, note the number on the connector pull-tab.
-

3. Loosen the captive screw that secures the mounting bracket to the drive-mounting shelf (see Figure 3–24).

Removing and Replacing FRUs

Figure 3–24 Removing the TZK10 Tape Drive



GA_EN00204A_92A

4. Lift the left side of the TZK10 tape drive. Slide the TZK10 tape drive to the left until the tabs on the right side of the mounting bracket are clear of the cutouts in the lower drive-mounting shelf.
5. Disconnect the power cable from the back of the TZK10 tape drive. Figure 1–3 shows the power cables in the BA42-B enclosure.
6. Disconnect the SCSI cable from the back of the TZK10 tape drive by pulling the pull-tab. Figure 1–4 shows the signal cables in the BA42-B enclosure.
7. Lift the TZK10 tape drive out of the system unit.


Removing and Replacing FRUs

3.8.1 Separating the TZK10 Tape Drive from the Mounting Bracket

When you install a replacement TZK10 tape drive, you must use the mounting bracket (74-42449-01) that is attached to the faulty TZK10 tape drive (TZK10-AA). To separate the mounting bracket from the faulty TZK10 tape drive, follow these steps:

1. Remove the four screws (90-10961-03) that secure the mounting bracket to the TZK10 tape drive (see Figure 3–25).
2. Separate the mounting bracket from the TZK10 tape drive.

Figure 3–25 Separating the Mounting Bracket from the TZK10 Tape Drive



GA_EN00205A_92A

Removing and Replacing FRUs

3. Keep the mounting bracket and the four screws in a safe place because you must use them to install the replacement TZK10 tape drive.

Note

When you attach the mounting bracket to the replacement TZK10 tape drive, align the holes on the mounting bracket that are marked by a *Q* with the screw holes on the sides of the TZK10 tape drive.


3.8.2 Setting the SCSI ID of the Replacement TZK10 Tape Drive

To set the SCSI ID of the replacement TZK10 tape drive, follow these steps:

1. Note the positions of the SCSI ID jumper wires on the TZK10 tape drive you removed. Figure 3–26 shows the location of the SCSI ID jumper wires and the recommended SCSI ID for tape drives.
2. Set the SCSI ID jumper wires on the replacement TZK10 tape drive to the same positions as the SCSI ID switches of the TZK10 tape drive you removed.

Removing and Replacing FRUs

Figure 3–26 Locations of the SCSI ID Jumper Wires on the TZK10 Tape Drive



GA_EN00206A_92A

See the *Options* manual for more information about setting the SCSI ID of the TZK10 tape drives.

3.9 Removing a TLZ06 Tape Drive

The TLZ06 tape drive (when installed) can be on the right side or the left side of the lower drive-mounting shelf, when viewed from the front. The following procedure describes how to remove a TLZ06 tape drive from the right side of the lower drive-mounting shelf. The procedure for removing the TLZ06 tape drive from the left side of the lower drive-mounting shelf is the same. To remove a TLZ06 tape drive from the BA42-B enclosure, follow these steps:

Removing and Replacing FRUs

1. Remove the enclosure cover (see Section 3.1).
2. Remove the upper drive-mounting shelf (see Section 3.4).


Note

- You can disconnect the cables from the drive more easily after you remove the drive from the drive-mounting shelf.
 - When you disconnect the cables, note which cables connect to which drives. On the SCSI cable, note the number on the connector pull-tab.
-

3. Loosen the captive screw that secures the mounting bracket to the drive-mounting shelf (see Figure 3–27).

Removing and Replacing FRUs

Figure 3–27 Removing the TLZ06 Tape Drive



GA_EN00142A_92A

4. Lift the left side of the TLZ06 tape drive. Slide the TLZ06 tape drive to the left until the tabs on the right side of the mounting bracket are clear of the cutouts in the lower drive-mounting shelf.
5. Disconnect the power cable from the back of the TLZ06 tape drive. Figure 1–3 shows the power cables in the BA42-B enclosure.
6. Disconnect the SCSI cable from the back of the TLZ06 tape drive by pulling the pull-tab. Figure 1–4 shows the signal cables in the BA42-B enclosure.
7. Lift the TLZ06 tape drive out of the system unit.


Removing and Replacing FRUs

3.9.1 Separating the TLZ06 Tape Drive from the Mounting Bracket

When you install a replacement TLZ06 tape drive, you must use the mounting bracket (74-42449-01) that is attached to the faulty TLZ06 tape drive (TLZ06-AA). To separate the mounting bracket from the faulty TLZ06 tape drive, follow these steps:

1. Remove the four screws (90-10961-03) that secure the mounting bracket to the TLZ06 tape drive (see Figure 3–28).
2. Separate the mounting bracket from the TLZ06 tape drive.

Figure 3–28 Separating the Mounting Bracket from the TLZ06 Tape Drive



Removing and Replacing FRUs

3. Keep the mounting bracket and the four screws in a safe place because you must use them to install the replacement TLZ06 tape drive.

Note

When you attach the mounting bracket to the replacement TLZ06 tape drive, align the holes on the mounting bracket that are marked by a *Q* with the screw holes on the sides of the TLZ06 tape drive.


3.9.2 Setting the SCSI ID and Option Switches of the Replacement TLZ06 Tape Drive

To set the SCSI ID and option switches of the replacement TLZ06 tape drive, follow these steps:

1. Note the positions of the SCSI ID and option switches on the TLZ06 tape drive you removed. Figure 3–29 shows the location of the SCSI ID and option switches and the recommended SCSI ID for tape drives.
2. Set the SCSI ID and option switches on the replacement TLZ06 tape drive to the same positions as the SCSI ID switches of the TLZ06 tape drive you removed.

Removing and Replacing FRUs

Figure 3–29 Locations of the SCSI ID and Option Switches on the TLZ06 Tape Drive



GA_EN00144A_92A

See the *Options* manual for more information about setting the SCSI ID and option switches on TLZ06 tape drives.

3.10 Removing an RRD42 CD-ROM Drive

The RRD42 CD-ROM drive (when installed) is on the left side of the lower drive-mounting shelf, when viewed from the front. To remove an RRD42 CD-ROM drive from the BA42-B enclosure, follow these steps:

1. Remove the enclosure cover (see Section 3.1).

Removing and Replacing FRUs

2. Remove the upper drive-mounting shelf (see Section 3.4).


Note

- You can disconnect the cables from the drive more easily after you remove the drive from the drive-mounting shelf.
 - When you disconnect the cables, you must note which cables connect to which drives. On the SCSI cable, note the number on the connector pull-tab.
-

3. Loosen the captive screw that secures the mounting bracket to the drive-mounting shelf (see Figure 3–30).

Removing and Replacing FRUs

Figure 3–30 Removing the RRD42 CD-ROM Drive



GA_EN00207A_92A

4. Lift the right side of the RRD42 CD-ROM drive. Slide the RRD42 CD-ROM drive to the right until the tabs on the left side of the mounting bracket are clear of the cutouts in the lower drive-mounting shelf.
5. Disconnect the power cable from the back of the RRD42 CD-ROM drive. Figure 1–3 shows the power cables in the BA42-B enclosure.
6. Disconnect the SCSI cable from the back of the RRD42 CD-ROM drive by pulling the pull-tab. Figure 1–4 shows the signal cables in the BA42-B enclosure.
7. Lift the RRD42 CD-ROM drive, which has its bracket attached, out of the system unit.

Caution

The RRD42 CD-ROM drive has a plastic cover that protects the drive from dust. Do not remove this cover when replacing the RRD42

Removing and Replacing FRUs


CD-ROM drive or setting the SCSI ID.

3.10.1 Separating the RRD42 CD-ROM Drive from the Mounting Bracket

When you install a replacement RRD42 CD-ROM drive, you must use the mounting bracket (74-42449-01) that is attached to the faulty RRD42 CD-ROM drive (RRD42-AA). To separate the mounting bracket from the faulty RRD42 CD-ROM drive, follow these steps:

1. Remove the four screws (90-10961-03) that secure the mounting bracket to the RRD42 CD-ROM drive.
2. Separate the mounting bracket from the RRD42 CD-ROM drive (see Figure 3-31).

Figure 3-31 Separating the Mounting Bracket from the RRD42 CD-ROM Drive



3. Keep the mounting bracket and the four screws in a safe place because you must use the same bracket and screws to install the replacement RRD42 CD-ROM drive.

Removing and Replacing FRUs

Note

When you attach the mounting bracket to the replacement RRD42 CD-ROM drive, align the holes on the mounting bracket that are not marked by a *Q* with the screw holes on the sides of the RRD42 CD-ROM drive.


3.10.2 Setting the SCSI ID on the Replacement RRD42 CD-ROM Drive

To set the SCSI ID on the replacement RRD42 CD-ROM drive, follow these steps:

1. Note the SCSI ID jumper wires on the RRD42 CD-ROM drive you removed. Figure 3–32 shows the location of the SCSI ID jumper wires.
2. Set the SCSI ID jumper wires on the replacement RRD42 CD-ROM drive to the same positions as the SCSI ID jumper wires on the RRD42 CD-ROM drive you removed.

Removing and Replacing FRUs

Figure 3-32 RRD42 SCSI ID Jumper Wire Locations



GA_EN00209A_92A

See the *Options* manual for more information about setting the SCSI ID of the RRD42 CD-ROM drive.

3.11 Removing the Upper and Lower Drive-Mounting Shelf Combination

Caution

Static electricity can damage integrated circuits. Wear a wrist strap and place an antistatic mat under the system unit when working with the internal parts of the system unit.


Removing and Replacing FRUs

To reach the CPU module and some of the components that connect to it, you must remove the upper drive-mounting shelf and the lower drive-mounting shelf. To save time, you can remove both of the drive-mounting shelves as one unit with the devices and cables in place. To remove the upper and lower drive-mounting shelf combination, follow these steps:

1. On the power supply unit, disconnect the power cables that supply power to the upper and lower drive-mounting shelves.
2. Loosen the two captive screws that secure the upper drive-mounting shelf to the power supply unit (see Figure 3-33).
3. Loosen the two captive screws that secure the lower drive-mounting shelf to the enclosure (see Figure 3-33).
4. Loosen the two Philips screws (90-09984-07) that secure the lower drive-mounting shelf to the enclosure (see Figure 3-33).

Removing and Replacing FRUs

Figure 3–33 Removing the Upper and Lower Drive-Mounting Shelf Combination



5. Slide the upper and lower drive-mounting shelf combination towards the front of the enclosure as far as it will go.


Caution

When you disconnect the SCSI cable from the CPU module, ensure that you do not damage any of the MS44 or MS44L memory modules.

6. Disconnect the SCSI cable from the CPU module (see Figure 3–34).

Removing and Replacing FRUs

Figure 3-34 Disconnecting the SCSI Cable



RE_EN06244A_91

7. Lift the upper and lower drive-mounting shelf combination out of the system enclosure with the devices and cables in place.


3.12 Removing the SCSI Cable

To remove the SCSI cable from the BA42-B enclosure, follow these steps:

1. Remove the upper and lower drive-mounting shelf combination (see Section 3.11).
2. Disconnect the SCSI cable from the disk drives on the upper drive-mounting shelf.
3. Loosen the captive screw that secures the upper drive-mounting shelf to the lower drive-mounting shelf (see Figure 3-35).

Removing and Replacing FRUs

Figure 3–35 Separating the Upper Drive-Mounting Shelf from the Lower Drive-Mounting Shelf



RE_EN06490A_91


4. Lift the left side of the upper drive-mounting shelf and slide it to the left until the tabs on the right side of the upper drive-mounting shelf are released from the cutouts in the lower drive-mounting shelf.
5. Disconnect the SCSI cable from the mass storage devices on the lower drive-mounting shelf.

To release the SCSI cable, follow steps six to eight for Model 40 and Model 80 systems or step nine for Model 90 systems:

6. Push the tab on the cable clamp (90-11237-01) (see Figure 3–36), and tilt the cable clamp towards the back of the lower drive-mounting shelf.

Removing and Replacing FRUs

Figure 3–36 Releasing the SCSI Cable Clamp (Model 40 and Model 80 Only)




RE_EN06491A_91

7. Release the cable clamp from its cutout in the lower drive-mounting shelf.
8. Turn the cable and the cable clamp through 90° and slide the cable out through the slot in the lower drive-mounting shelf (see Figure 3–36).
The next step is for model 90 systems only.
9. Twist the cable through 90° and pull through the slot as shown in Figure 3–37.

Removing and Replacing FRUs

Figure 3-37 Releasing the SCSI Cable (Model 90 Only)



RE_EN06491A_91

3.13 Removing the DSW42 Synchronous Communications Option

The DSW42 synchronous communications option contains three components that you must remove from the CPU module as follows:

- A logic board (54-20640-01)
- An input/output cable (17-02942-01)
- An input/output module (70-28542-01)

Removing and Replacing FRUs

To remove the DSW42 synchronous communications option from the BA42-B enclosure, follow these steps:

1. Remove the enclosure cover (see Section 3.1).
2. Remove the upper and lower drive-mounting shelf combination (see Section 3.11).
3. Remove the logic board, the input/output cable, and the input/output module according to the procedures in the following subsections.

3.13.1 Removing the DSW42 Logic Board

Caution

Static electricity can damage integrated circuits. Wear a wrist strap and place an antistatic mat under the system unit when working with the internal parts of the system unit.


1. Press the latch on one of the standoff pillars (see Figure 3-38) and push up the corner of the DSW42 logic board until the DSW42 logic board is released.

Note

The standoff pillars contain two components: a push-button rivet (12-35477-02) and a standoff (12-35477-03). On model 90 systems, the standoff pillars are in the opposite corners to the standoff pillars on model 40 and 80 logic boards.

Removing and Replacing FRUs

Figure 3–38 Removing the DSW42 Logic Board



2. Press the latch on the other standoff pillar and push up that corner of the DSW42 logic board until the DSW42 logic board is released.
3. Push up the DSW42 logic board until the connectors on the DSW42 logic board disengage from the connectors on the CPU module (see Figure 3–38).
4. Remove the DSW42 logic board from the enclosure.

3.13.2 Removing the DSW42 Input/Output Cable


To remove the DSW42 input/output cable, follow these steps:

1. Disconnect the DSW42 input/output cable from the CPU module (see Figure 3–39).
2. Disconnect the DSW42 input/output cable from the DSW42 input/output module on the back of the enclosure (see Figure 3–39).

Removing and Replacing FRUs

3. Remove the DSW42 input/output cable from the enclosure.

Figure 3–39 Removing the DSW42 Input/Output Cable



RE_EN06248A_91

3.13.3 Removing the DSW42 Input/Output Module


To remove the DSW42 input/output module, follow these steps:

1. Disconnect the external cables that connect to synchronous ports 0 and 1 on the back of the system unit (if not already disconnected).
2. Disconnect the DSW42 input/output cable from the DSW42 input/output module (if not already disconnected).
3. Press the spring clip on the DSW42 input/output module. Pull the DSW42 input/output module towards the front of the enclosure until it is released from the back of the enclosure (see Figure 3–40).

Removing and Replacing FRUs

4. Lift up and remove the DSW42 input/output module from the enclosure.

Figure 3–40 Removing the DSW42 Input/Output Module



RE_EN06249A_91

3.14 Removing the DHW42 Asynchronous Communications Option

The DHW42 asynchronous communications option contains three components that you must remove from the system enclosure as follows:

- A logic board (54-20662-01)
- An input/output cable (17-02942-01)
- One of the following input/output modules:
 - 8 data-only line input/output module (70-28542-02)
 - 16 data-only line input/output module (70-28542-03)

Removing and Replacing FRUs

- 8 modem control line input/output module (70-28543-01)

To remove the DHW42 asynchronous communications option from the BA42-B enclosure, follow these steps:

1. Remove the enclosure cover (see Section 3.1).
2. Remove the upper and lower drive-mounting shelf combination (see Section 3.11).
3. Remove the logic board, the input/output cable, and the input/output module according to the procedures in the following subsections.

3.14.1 Removing the DHW42 Logic Board

Caution

Static electricity can damage integrated circuits. Wear a wrist strap and place an antistatic mat under the system unit when working with the internal parts of the system unit.


1. Press the latch on one of the standoff pillars (see Figure 3-41) and push up the corner of the DHW42 logic board until the DHW42 logic board is released.

Note

- On Model 90 systems, the DHW42 logic board is located on the left hand side of the KA50 CPU module.
 - The standoff pillars contain two components: a push-button rivet (12-35477-02) and a standoff (12-35477-03).
-

Removing and Replacing FRUs

Figure 3–41 Removing the DHW42 Logic Board



2. Press the latch on the other standoff pillar and push up the corner of the DHW42 logic board until the latch releases the DHW42 logic board.
3. Push up the DHW42 logic board until the connectors on the DHW42 logic board disengage from the connectors on the CPU module (see Figure 3–41).
4. Remove the DHW42 logic board from the enclosure.

3.14.2 Removing the DHW42 Input/Output Cable


To remove the DHW42 input/output cable, follow these steps:

1. Disconnect the DHW42 input/output cable from the CPU module (see Figure 3–42).
2. Disconnect the DHW42 input/output cable from the DHW42 input/output module on the back of the enclosure (see Figure 3–42).

Removing and Replacing FRUs

3. Remove the DHW42 input/output cable from the enclosure.

Figure 3–42 Removing the DHW42 Input/Output Cable



RE_EN06251A_91

3.14.3 Removing the DHW42 Input/Output Module


To remove the DHW42 input/output module, follow these steps:

1. Disconnect the external cables that are connected to asynchronous ports A and B on the back of the system unit (if not already disconnected).
2. Disconnect the DHW42 input/output cable from the DHW42 input/output module (if not already disconnected).
3. Press the spring clip on the DHW42 input/output module. Pull the DHW42 input/output module towards the front of the enclosure until it is released from the back of the enclosure (see Figure 3–43).

Removing and Replacing FRUs

4. Lift up and remove the DHW42 input/output module from the enclosure.

Figure 3–43 Removing the DHW42 Input/Output Module



RE_EN06252A_91

Removing and Replacing FRUs


3.15 Removing the CPU Module

To remove the CPU module from the BA42-B enclosure, follow these steps:

1. Disconnect the external cables, loopback connectors, and terminators from the back of the system unit.
2. Remove the enclosure cover (see Section 3.1).
3. Remove the upper and lower drive-mounting shelf combination (see Section 3.11).
4. If installed, remove the DSW42 logic board (see Section 3.13.1) and disconnect the DSW42 input/output cable from the CPU module (see Section 3.13.2).
5. If installed, remove the DHW42 logic board (see Section 3.14.1) and disconnect the DHW42 input/output cable from the CPU module (see Section 3.14.2).
6. Disconnect the MS44 or MS44L memory modules from the CPU module (see Section 3.2).
7. Disconnect the power cable from the CPU module (see Figure 3-44).
8. Disconnect the 3.3 V dc cable (17-03136-01, Model 80 systems only) from the CPU module (see Figure 3-44).

Removing and Replacing FRUs

Figure 3-44 Disconnecting the Cables from the CPU Module



RE_EN06253A_91

9. Disconnect the SCSI ribbon cable (17-02944-01) from the CPU module (see Figure 3-44).

Caution


Ensure that you do not damage any of the CPU module components by exerting too much force on the components.

Removing and Replacing FRUs

10. Press the two spring clips (marked by arrows in Figure 3–45) that secure the CPU module in position. The CPU module moves forward under the tension of the connector gaskets. If necessary, slide the CPU module back until it disengages from the ten keyhole cutouts (see Figure 3–45).
11. Use your finger, in the semicircular cutout on the front edge of the CPU module, to lift up the front edge of the CPU module (see Figure 3–45).
12. While supporting the front of the CPU module with one hand, guide the connectors on the back of the CPU module out of the corresponding cutouts on the back of the enclosure.
13. Carefully remove the Ethernet ID ROM from the CPU module. You must install this ROM in the replacement CPU module.
14. Remove the CPU module from the enclosure.

Removing and Replacing FRUs

Figure 3-45 Removing the CPU Module



RE_EN06254A_91

Removing and Replacing FRUs

3.16 Replacing the CPU Module

To install a replacement CPU module in a BA42-B enclosure, follow these steps:

Caution

Static electricity can damage integrated circuits. Wear a wrist strap and place an antistatic mat under the system when working with the internal parts of the system unit.


Caution

You can damage the ROM or the CPU module by installing the ROM with an incorrect orientation.

1. Install the Ethernet ID ROM that you removed from the original CPU module on the replacement CPU module. Figure 3-46 shows the location and orientation of the Ethernet ID ROM for models 40 and 80. Figure 3-47 shows the location and orientation of the Ethernet ID ROM for models 90.


Removing and Replacing FRUs

Figure 3–46 Location and Orientation of the Ethernet ID ROM for Models 40 and 80



Removing and Replacing FRUs

Figure 3-47 Location and Orientation of the Ethernet ID ROM for Model 90



2. Place the CPU module in the enclosure so that the connectors on the CPU module align with the corresponding cutouts in the back panel of the enclosure. Use the ThinWire Ethernet port as an anchor point to adjust the position of the CPU module correctly.
3. Align the keyhole cutouts in the CPU module with the corresponding standoff pillars in the base of the enclosure.

Caution

Ensure that you do not damage any of the CPU module components by exerting pressure on the components.

4. Press the CPU module at the two positions marked *push*. The spring clips push the standoff pillars into the keyhole cutouts that secure the CPU module in position.
5. Connect the SCSI ribbon cable (17-02944-01) to the CPU module (see Figure 3-44 for the location of the SCSI ribbon cable).
6. Connect the power cable (Model 40) or the power cables (Model 80) to the CPU module (see Figure 3-44 for the location of the power cables).

Removing and Replacing FRUs

7. Install the MS44 and MS44L memory modules that you removed from the original CPU module. Follow the steps in Section 3.2 in reverse order to install the memory modules
8. Install the DSW42 logic board, and connect the DSW42 input/output cable if fitted. Follow the steps in Section 3.13.1 and Section 3.13.2 in reverse order to install the logic board and cable.
9. Install the DHW42 logic board, and connect the DHW42 input/output cable if fitted. Follow the steps in Section 3.14.1 and Section 3.14.2 in reverse order to install the logic board and cable.
10. Install the upper and lower drive-mounting shelf combination. Follow the steps in Section 3.11 in reverse order to install the drive-mounting shelf combination.
11. Install the enclosure cover. Follow the steps in Section 3.1 in reverse order to install the cover.

3.17 Removing the Power Supply Unit

Note


In MicroVAX 3100 platform systems, the power supply unit (30-35042-01) is a single FRU. It does not have any replaceable components.

To remove the power supply unit from the BA42-B enclosure, follow these steps:

1. Disconnect the power supply.
2. Remove the enclosure cover (see Section 3.1).
3. Remove the upper and lower drive-mounting shelf combination (see Section 3.11).
4. Disconnect the power cable and the 3.3 V dc cable (Model 80 systems only) from the CPU module (see Figure 3-44).
5. Loosen the two captive screws (see Figure 3-48).

Removing and Replacing FRUs

Figure 3–48 Removing the Power Supply Unit



RE_EN06255A_91

6. Loosen the two Philips screws (90-09984-07) that secure the power supply unit to the left side of the enclosure (see Figure 3–48).

Caution

Ensure that you do not damage any of the MS44 or MS44L memory modules when you lift the power supply unit out of the enclosure.

7. Lift the front of the power supply unit (see Figure 3–48).
8. Remove the power supply unit from the enclosure.


A

Pin Specifications for the Ports on the BA42-B System

Figure A-1 shows the pin specifications for the ports on the BA42-B system.

Pin Specifications for the Ports on the BA42-B System

Figure A-1 Pin Specifications for the Ports on the BA42-B System



Pin Specifications for the Ports on the BA42-B System

Table A-1 Asynchronous Port A and Port B Pin Specifications for the Eight-Data and 16-Data Line Options

Contact	Port A Signal Name ²	Port B ¹ Signal Name ²
1	LINE 0 TRANSMIT H	LINE 8 TRANSMIT H
2	LINE 0 RECEIVE H	LINE 8 RECEIVE H
3	LINE 1 TRANSMIT H	LINE 9 TRANSMIT H
4	LINE 1 RECEIVE H	LINE 9 RECEIVE H
5	LINE 2 TRANSMIT H	LINE 10 TRANSMIT H
6	LINE 2 RECEIVE H	LINE 10 RECEIVE H
7	LINE 3 TRANSMIT H	LINE 11 TRANSMIT H
8	LINE 3 RECEIVE H	LINE 11 RECEIVE H
9	LINE 4 TRANSMIT H	LINE 12 TRANSMIT H
10	LINE 4 RECEIVE H	LINE 12 RECEIVE H
11	LINE 5 TRANSMIT H	LINE 13 TRANSMIT H
12	LINE 5 RECEIVE H	LINE 13 RECEIVE H
13	LINE 6 TRANSMIT H	LINE 14 TRANSMIT H
14	LINE 6 RECEIVE H	LINE 14 RECEIVE H
15	LINE 7 TRANSMIT H	LINE 15 TRANSMIT H
16	LINE 7 RECEIVE H	LINE 15 RECEIVE H
17	150 OHMS TO GROUND	150 OHMS TO GROUND
18	150 OHMS TO GROUND	150 OHMS TO GROUND
19	LINE 0 TRANSMIT L	LINE 8 TRANSMIT L
20	LINE 0 RECEIVE L	LINE 8 RECEIVE L
21	LINE 1 TRANSMIT L	LINE 9 TRANSMIT L
22	LINE 1 RECEIVE L	LINE 9 RECEIVE L
23	LINE 2 TRANSMIT L	LINE 10 TRANSMIT L
24	LINE 2 RECEIVE L	LINE 10 RECEIVE L
25	LINE 3 TRANSMIT L	LINE 11 TRANSMIT L
26	LINE 3 RECEIVE L	LINE 11 RECEIVE L

¹Not applicable to eight-data line option.

²The signal names ending with L are active low; the signal names ending with H are active high.

(continued on next page)

Pin Specifications for the Ports on the BA42-B System

Table A–1 (Cont.) Asynchronous Port A and Port B Pin Specifications for the Eight-Data and 16-Data Line Options

Contact	Port A Signal Name ²	Port B ¹ Signal Name ²
27	LINE 4 TRANSMIT L	LINE 12 TRANSMIT L
28	LINE 4 RECEIVE L	LINE 12 RECEIVE L
29	LINE 5 TRANSMIT L	LINE 13 TRANSMIT L
30	LINE 5 RECEIVE L	LINE 13 RECEIVE L
31	LINE 6 TRANSMIT L	LINE 14 TRANSMIT L
32	LINE 6 RECEIVE L	LINE 14 RECEIVE L
33	LINE 7 TRANSMIT L	LINE 15 TRANSMIT L
34	LINE 7 RECEIVE L	LINE 15 RECEIVE L
35	150 OHMS TO GROUND	150 OHMS TO GROUND
36	150 OHMS TO GROUND	150 OHMS TO GROUND

¹Not applicable to eight-data line option.

²The signal names ending with L are active low; the signal names ending with H are active high.

Table A–2 Asynchronous Port A and Port B Pin Specifications for the Eight-Modem Control Line Option

Contact	Port A Signal Name ¹	Port B Signal Name ¹
1	LINE 0 TX CONN L	LINE 4 TX CONN L
2	LINE 0 RX CONN L	LINE 4 RX CONN L
3	LINE RTS CONN<0> H	LINE RTS CONN<4> H
4	LINE 0 CTS CONN H	LINE 4 CTS CONN H
5	LINE 0 DSR CONN H	LINE 4 DSR CONN H
6	LINE 0 SGND CONN L	LINE 4 SGND CONN L
7	LINE 0 CD CONN H	LINE 4 CD CONN H
8	LINE 0 SPDMI CONN H	LINE 4 SPDMI CONN H
9	LINE DTR CONN<0> H	LINE DTR CONN<4> H

¹The signal names ending with L are active low; the signal names ending with H are active high.

(continued on next page)

Pin Specifications for the Ports on the BA42-B System

Table A-2 (Cont.) Asynchronous Port A and Port B Pin Specifications for the Eight-Modem Control Line Option

Contact	Port A Signal Name ¹	Port B Signal Name ¹
10	LINE 0 RI CONN H	LINE 4 RI CONN H
11		
12	LINE DSRS CONN<0> H	LINE DSRS CONN<4> H
13	LINE 1 TX CONN L	LINE 5 TX CONN L
14	LINE 1 RX CONN L	LINE 5 RX CONN L
15	LINE RTS CONN<1> H	LINE RTS CONN<5> H
16	LINE 1 CTS CONN H	LINE 5 CTS CONN H
17	LINE 1 DSR CONN H	LINE 5 DSR CONN H
18	LINE 1 SGND CONN L	LINE 5 SGND CONN L
19	LINE 1 CD CONN H	LINE 5 CD CONN H
20	LINE 1 SPDMI CONN H	LINE 5 SPDMI CONN H
21	LINE DTR CONN<1> H	LINE DTR CONN<5> H
22	LINE 1 RI CONN H	LINE 5 RI CONN H
23		
24	LINE DSRS CONN<1> H	LINE DSRS CONN<5> H
25	LINE 2 TX CONN L	LINE 6 TX CONN L
26	LINE 2 RX CONN L	LINE 6 RX CONN L
27	LINE RTS CONN<2> H	LINE RTS CONN<6> H
28	LINE 2 CTS CONN H	LINE 6 CTS CONN H
29	LINE 2 DSR CONN H	LINE 6 DSR CONN H
30	LINE 2 SGND CONN L	LINE 6 SGND CONN L
31	LINE 2 CD CONN H	LINE 6 CD CONN H
32	LINE 2 SPDMI CONN H	LINE 6 SPDMI CONN H
33	LINE DTR CONN<2> H	LINE DTR CONN<6> H
34	LINE 2 RI CONN H	LINE 6 RI CONN H
35		
36	LINE DSRS CONN<2> H	LINE DSRS CONN<6> H

¹The signal names ending with L are active low; the signal names ending with H are active high.

(continued on next page)

Pin Specifications for the Ports on the BA42-B System

Table A–2 (Cont.) Asynchronous Port A and Port B Pin Specifications for the Eight-Modem Control Line Option

Contact	Port A Signal Name ¹	Port B Signal Name ¹
37	LINE 3 TX CONN L	LINE 7 TX CONN L
38	LINE 3 RX CONN L	LINE 7 RX CONN L
39	LINE RTS CONN<3> H	LINE RTS CONN <7> H
40	LINE 3 CTS CONN H	LINE 7 CTS CONN H
41	LINE 3 DSR CONN H	LINE 7 DSR CONN H
42	LINE 3 SGND CONN L	LINE 7 SGND CONN L
43	LINE 3 CD CONN H	LINE 7 CD CONN H
44	LINE 3 SPDMI CONN H	LINE 7 SPDMI CONN H
45	LINE DTR CONN<3> H	LINE DTR CONN<7> H
46	LINE 3 RI CONN H	LINE 7 RI CONN H
47		
48	LINE DSRS CONN<3> H	LINE DSRS CONN<7> H
49		
50		

¹The signal names ending with L are active low; the signal names ending with H are active high.

Table A–3 Pin Specifications for Synchronous Port 0 and Port 1

Contact	Port 0 Signal Name ¹	Port 1 Signal Name ¹
1	CODE GND 1 L	CODE GND 2 L
2	CODE0 1 L	CODE0 2 L
3	CODE1 1 L	CODE1 2 L
4	CODE2 1 L	CODE2 2 L
5	CODE3 1 L	CODE3 2 L
6	TXDATA(B) 1 P L	TXDATA(B) 2 P L

¹The signal names ending with L are active low; the signal names ending with H are active high.

(continued on next page)

Pin Specifications for the Ports on the BA42-B System

Table A-3 (Cont.) Pin Specifications for Synchronous Port 0 and Port 1

Contact	Port 0 Signal Name ¹	Port 1 Signal Name ¹
7	TXDATA(A) 1 P H	TXDATA(A) 2 P H
8	TXDATA 1 P L	TXDATA 2 P L
9	RTS/C A 1 P L	RTS/C A 2 P L
10	RTS/C B 1 P L	RTS/C B 2 P L
11	RX DATA A 1 P L	RX DATA A 2 P L
12	RX DATA B 1 P L	RX DATA B 2 P L
13	LOCAL LOOP 1 P H	LOCAL LOOP 2 P H
14	TEST 4 1 P L	TEST 4 2 P L
15	TEST 11 1 P H	TEST 11 2 P H
16	REM LOOP 1 P H	REM LOOP 2 P H
17	R1 1 P H	R1 2 P H
18	RXCLOCK A 1 P L	RXCLOCK A 2 P L
19	RXCLOCK B 1 P H	RXCLOCK B 2 P H
20	TXCLOCK A 1 P L	TXCLOCK A 2 P L
21	TXCLOCK B 1 P H	TXCLOCK B 2 P H
22	CLOCK 1 P L	CLOCK 2 P L
23	V35 TXCLK A 1 P L	V35 TXCLK A 2 P L
24	V35 TXCLK B 1 P H	V35 TXCLK B 2 P H
25	V35 CLK A 1 P L	V35 CLK A 2 P L
26	V35 CLK B 1 P H	V35 CLK B 2 P H
27	V35 RX A 1 P L	V35 RX A 2 P L
28	V35 RX B 1 P H	V35 RX B 2 P H
29	V35 TX A 1 P L	V35 TX A 2 P L
30	V35 TX B 1 P H	V35 TX B 2 P H
31	V35 RXCLK A 1 P L	V35 RXCLK A 2 P L
32	V35 RXCLK B 1 P H	V35 RXCLK B 2 P H
33	DTR 1 P H	DTR 2 P H

¹The signal names ending with L are active low; the signal names ending with H are active high.

(continued on next page)

Pin Specifications for the Ports on the BA42-B System

Table A–3 (Cont.) Pin Specifications for Synchronous Port 0 and Port 1

Contact	Port 0 Signal Name ¹	Port 1 Signal Name ¹
34	DSR A 1 P H	DSR A 2 P H
35	DSR B 1 P L	DSR B 2 P L
36	RTS 1 P L	RTS 2 P L
37	DCD/I A 1 P H	DCD/I A 2 P H
38	DCD/I B 1 P L	DCD/I B 2 P L
39	CTS A 1 P H	CTS A 2 P H
40	CTS B 1 P L	CTS B 2 P L
42	TEST 1 1 P H	TEST 1 2 P H
43	TEST 2 1 P H	TEST 2 2 P H
44	DTE GND 1 PROT L	DTE GND 2 PROT L
45	DTR A 1 P H	DTR A 2 P H
46	DTR B 1 P L	DTR B 2 P L
47	CLOCK A 1 P L	CLOCK A 2 P L
48	CLOCK B 1 P H	CLOCK B 2 P H
49	TEST 3 1 P H	TEST 3 2 P H
50	SPEED SEL 1 P H	SPEED SEL 2 P H

¹The signal names ending with L are active low; the signal names ending with H are active high.

Pin Specifications for the Ports on the BA42-B System

Table A-4 Pin Specifications for the External SCSI Connector

Contact	Signal Name ¹	Contact	Signal Name ¹
1	GROUND	26	TERMPWR
2	DB (0) L	27	RESERVED
3	GROUND	28	RESERVED
4	DB (1) L	29	GROUND
5	GROUND	30	GROUND
6	DB (2) L	31	GROUND
7	GROUND	32	ATN L
8	DB (3) L	33	GROUND
9	GROUND	34	GROUND
10	DB (4) L	35	GROUND
11	GROUND	36	BSY L
12	DB (5) L	37	GROUND
13	GROUND	38	ACK L
14	DB (6) L	39	GROUND
15	GROUND	40	RST L
16	DB (7) L	41	GROUND
17	GROUND	42	MSG L
18	DB (P) L	43	GROUND
19	GROUND	44	SEL L
20	GROUND	45	GROUND
21	GROUND	46	C/D L
22	GROUND	47	GROUND
23	RESERVED	48	REQ L
24	RESERVED	49	GROUND
25	OPEN	50	I/O L

¹The signal names ending with L are active low; the signal names ending with H are active high.

B

Recommended Spare Parts List

Table B-1 gives a list of the recommended spare parts for the MicroVAX 3100 Model 40 and Model 80 systems that use the BA42-B enclosure.

Table B-1 Recommended Spare Parts

Description ¹	Part Number	Quantity
CPU module, KA45-AA (SOC)	54-20654-01	1
CPU module, KA47-AA (Mariah)	54-20652-01	1
CPU module, KA50-AA (NVAX)	54-21797-01	1
Cable assembly, SCSI A internal loop	17-02943-01	1
SCSI cable clamp	90-11237-01	1
Cable assembly, SCSI A/B, CPU to I/O	17-02944-01	1
Terminator, 50-way SCSI (H8574-A)	12-30552-01	1
Loopback connector, standard Ethernet	12-22196-01	1
T-connector, ThinWire Ethernet (H8223)	12-25869-01	1
Terminator, ThinWire Ethernet, 50-ohm (H8225)	12-26318-01	2
Loopback connector, modem port, 25-way	29-24795-00	1
Adapter, 25-way EIA-232 to 6-way MMJ	H8575-A	1
Memory module, MS44-AA (4M bytes)	54-19103-AA	1
Memory module, MS44L-AA (4M bytes)	MS44L-AA	1
Memory module, MS44-CA (16M bytes)	54-19103-CA	1
Power supply unit (H7829-AA)	30-35042-01	1
Cable assembly, dc harness, upper shelf	17-02219-01	1

¹The major FRUs are the entries in this column that are not indented. This manual gives instructions on how to replace these FRUs.

(continued on next page)

Recommended Spare Parts List

Table B–1 (Cont.) Recommended Spare Parts

Description ¹	Part Number	Quantity
Cable assembly, dc harness, lower shelf	17-03018-01	1
Cable assembly, 3.3 V dc harness	17-03136-01	1
RX26 diskette drive	RX26-AA	1
Cable assembly, RX26 to SCSI/FDI board	17-00285-00	1
RX26 SCSI/FDI board	54-20764-02	1
RZ23L disk drive	RZ23L-E	1
RZ24 disk drive	RZ24-E	1
RZ25 disk drive	RZ25-E	1
RZ26 disk drive	RZ26-E	1
RZ35 disk drive	RZ35-E	1
TZ30 tape drive	TZ30-AX	1
TZ30 take-up leader	74-34273-01	1
TZK10 tape drive	TZK10-AA	1
TLZ06 tape drive	TLZ06-AA	1
RRD42 CD-ROM drive	RRD42-AA	1
Asynchronous option, DHW42 logic board	54-20662-01	1
Asynchronous option, DHW42 input/output cable	17-02942-01	1
Asynchronous option, DHW42 input/output module (8-data only lines)	70-28542-02	1
Asynchronous option, DHW42 input/output module (16-data only lines)	70-28542-03	1
Cable assembly, asynchronous, 36-way Champ to harmonica	17-01174-01	1
System loopback connector (8- or 16-data only lines)	H3101-00	1
Cable loopback connector (8- or 16-data only lines)	H3101-00	1
Harmonica, 8-line distribution	H3104-00	1
Loopback connector, MMJ (H3103)	12-25083-01	1

¹The major FRUs are the entries in this column that are not indented. This manual gives instructions on how to replace these FRUs.

(continued on next page)

Recommended Spare Parts List

Table B–1 (Cont.) Recommended Spare Parts

Description ¹	Part Number	Quantity
Asynchronous option, DHW42 input/output module (8 modem control lines)	70-28543-01	1
Cable assembly, async, 50-way uchamp to four 25-way D-sub (BC29J-06)	17-02941-01	1
System loopback connector (4 modem control lines, H4081-A)	12-34212-01	1
Synchronous option, DSW42 logic board	54-20640-01	1
Synchronous option, input/output cable	17-02942-01	1
Synchronous option, input/output module (two lines)	70-28542-01	1
System loopback connector (H3199-00)	12-25852-01	2
Cable assembly, EIA-232/V.24 (BC19D-02)	17-01110-01	2
Cable assembly, EIA-423/V.10 (BC19E-02)	17-01111-01	2
Cable assembly, EIA-422/V.11 (BC19B-02)	17-01108-01	2
EIA-232/V.24 cable loopback connector	H3248-00	2
EIA-423/V.10 cable loopback connector (H3198-00)	12-26259-01	2
EIA-422/V.11 cable loopback connector (H3198-00)	12-26259-01	2
System power cord (USA)	17-00606-02	1
Terminal cable (BC16E-25)	17-00811-03	1
Antistatic kit	29-26246-00	1

¹The major FRUs are the entries in this column that are not indented. This manual gives instructions on how to replace these FRUs.

Glossary

The glossary defines some of the important terms used in this manual.

ac

alternating current.

CD-ROM

Compact disc read-only memory.

CPU

Central processing unit. The main unit of a computer containing the circuits that control the interpretation and execution of instructions. The CPU holds the main storage, arithmetic unit, and special registers.

dc

direct current.

ESD

Electrostatic discharge.

Ethernet

A type of local area network (LAN) based on carrier sense multiple access with collision detection (CSMA/DC).

FDI

Floppy diskette interface.

FRU

Field replaceable unit.

ground

A voltage reference in a system that has a zero voltage potential.

jumper wire

A short length of wire used to complete a circuit temporarily or to bypass a circuit.

LED

Light emitting diode.

MMJ

Modified modular jack.

module

A unit that contains electrical components and electrically conductive pathways between components.

port

A physical connector.

rms

root mean square. The root mean square value of an alternating voltage is the square root of the mean value of the square of the voltage values during a complete cycle.

ROM

Read-only memory.

SCSI

Small computer system interface. An interface designed for connecting disks and other peripheral devices to computer systems. SCSI is defined by an American National Standards Institute (ANSI) standard.

standard Ethernet

An IEEE 802.3 compliant Ethernet network composed of standard Ethernet cable as opposed to thin Ethernet cable.

system

A combination of system hardware, software, and peripheral devices that performs specific processing operations.

ThinWire

A trademark used to describe Digital's IEEE 802.3 compliant products used for local distribution of data communication.

Index

A

- Accessory tray, 2–5
- Air exhaust, 1–10
- Air flow
 - typical value, 1–10
- Air intake, 1–10
- Altitude
 - nonoperating, 2–4
 - operating, 2–4
- Asynchronous communications options
 - list of, 1–17
 - removing, 3–58
 - spare parts for, B–1

B

- BA42-B system
 - installing, 2–7
 - pin specifications, A–1
- Break/enable LED
 - function of, 1–5
 - location of, 1–3
- Break/enable switch
 - function of, 1–5
 - location of, 1–3

C

- Cable clamp
 - releasing (Models 40 and 80 only), 3–53
- Cable loopback connectors, B–1

- Cables
 - disconnecting from the CPU, 3–64
- CD-ROM drive
 - removing, 3–43
- Communications devices
 - list, 1–16
- Communications options
 - list of, 1–17
 - ports for, 1–3
- Configuration
 - communications options, 1–16
 - mass storage devices, 1–20
 - Model 40 memory, 1–10
 - Model 80 memory, 1–12 to 1–14
 - Model 90 memory, 1–14 to 1–16
 - system, 1–10
- Connectors
 - system unit, 1–3
- Console terminal
 - communication parameters, 2–7
 - connecting, 2–7
- Controls
 - system unit, 1–3
- Cover
 - removing, 3–5
- CPU module
 - removing, 3–63
 - replacing, 3–67

D

DHW42

removing, 3-58

DHW42 input/output cable

removing, 3-60

DHW42 input/output module

removing, 3-61

DHW42 logic board

removing, 3-59

Dimensions

BA42-B enclosure, 2-1

shipping container, 2-2

Disk drive

removing, 3-10

SCSI ID setting, 3-14

See RZ-series, 3-10, 3-14

Diskette drive

removing, 3-23

Drive-mounting shelves

function of, 1-20

removing, 3-48

DSW41

removing, 3-54

DSW42 input/output cable

removing, 3-56

DSW42 input/output module

removing, 3-57

DSW42 logic board

removing, 3-55

E

Electrical power

requirements, 2-5

Electrostatic discharge

See ESD, 2-3

Enclosure

description of, 1-1

removing cover, 3-5

ESD

effects of, 2-3

protection, 2-3

Ethernet ID ROM

location of, 3-67

orientation of, 3-67

Ethernet loopback connector

standard Ethernet, 2-12

Ethernet switch

function of, 1-5

location of, 1-3

Ethernet terminators

connecting, 2-10

F

FDI/SCSI board

removing, 3-25

Field replaceable unit

See FRU

Flying lead connector, 3-30

FRU

defined, 3-1

list, 3-3

locations, 3-3

section references, 3-3

H

Heat dissipation

typical value, 2-3

Humidity

nonoperating, 2-4

operating, 2-4

storage, 2-4

I

ID ROM

removing, 3-65

Indicators

function of, 1-3

power OK, 1-3

system unit, 1-3

Input/output module

DHW42, removing, 3-61

DSW42, removing, 3-57

Interconnection diagram, A-1

J

Jumper wires

- RRD42, 3-47
- RZ23L, 3-15
- RZ24, 3-16
- RZ25, 3-17
- RZ26, 3-18
- RZ35, 3-19
- TZK10, 3-37

K

- KA45 CPU module
 - removing, 3-63
- KA47 CPU module
 - removing, 3-63

L

- LED display, 1-6
- Logic board
 - DHW42, removing, 3-59
 - DSW42, removing, 3-55
- Loopback connectors
 - for system ports, B-1
 - standard Ethernet, 2-12

M

- Mass storage devices
 - combinations, 1-20
 - list, 1-20
 - orientation, 1-20
- Memory
 - expansion increments, 1-10, 1-12, 1-14
 - model 40 basic, 1-10
 - model 80 basic, 1-12
 - model 90 basic, 1-14
 - modules, 1-10, 1-12, 1-14, 3-6
- Memory expansion connectors
 - identification of, 1-10, 1-12, 1-14

- Model 40
 - basic system memory, 1-10
- Model 80
 - basic system memory, 1-12
- Model 90
 - basic system memory, 1-14
- Mounting bracket
 - RRD42, 3-46
 - RX26, 3-26
 - RZ25, 3-13
 - TLZ06, 3-41
 - TZ30, 3-31
 - TZK10, 3-36
- MS44-AA memory module
 - removing, 3-6
- MS44-CA memory module
 - removing, 3-6
- MS44L-AA memory module
 - removing, 3-6

N

Nonoperating conditions, 2-4

O

- On/Off switch
 - function of, 1-5
 - location of, 1-3
- Operating conditions, 2-4
- Option switches
 - TLZ06, 3-42

P

- Pin specifications, A-1
- Ports
 - asynchronous, 1-3
 - function of, 1-3
 - identifying, 1-3
 - location of, 1-3
 - MMJ, 1-3
 - SCSI, 1-3
 - synchronous, 1-3

- Power cord
 - connecting, 2–13
- Power distribution, 1–8 to 1–9
- Power OK indicator, 1–3
- Power requirements, 2–5
- Power supply unit
 - dc current outputs, 1–7
 - flying lead connector, 3–30
 - output power, 1–7
 - removing, 3–70
 - specifications, 1–7
- Power-on indicator, 1–3

R

- Recommended spare parts
 - list of, B–1
- RRD42 CD-ROM drive
 - mounting bracket, 3–46
 - removing, 3–43
 - SCSI ID setting, 3–47
- RX26 diskette drive
 - mounting bracket, 3–26
 - removing, 3–23
- RX26 FDI/SCSI board
 - removing, 3–25
 - SCSI ID setting, 3–27
- RZ-series disk drive
 - removing, 3–10
 - SCSI ID setting, 3–14
- RZ23L disk drive
 - removing, 3–10, 3–21
 - SCSI ID setting, 3–14
- RZ24 disk drive
 - removing, 3–10, 3–21
 - SCSI ID setting, 3–14
- RZ24L disk drive
 - removing, 3–10
- RZ25 disk drive
 - removing, 3–10, 3–21
 - SCSI ID setting, 3–14
- RZ26 disk drive
 - removing, 3–10
 - SCSI ID setting, 3–14
- RZ35 disk drive
 - removing, 3–10
 - SCSI ID setting, 3–14

S

- SCSI cable
 - releasing (Model 90 only), 3–53
 - removing, 3–51
- SCSI ID
 - RRD42 jumper wire locations, 3–47
 - RX26 switch locations, 3–27, 3–28
 - RZ23L jumper wire locations, 3–15
 - RZ24 jumper wire locations, 3–16
 - RZ25 jumper wire locations, 3–17
 - RZ26 jumper wire locations, 3–18
 - RZ35 jumper wire locations, 3–19
 - setting on RZ-series disk drives, 3–14
 - TLZ06 SCSI ID and option switches
 - location, 3–42
 - TZ30 switch locations, 3–32
 - TZK10 jumper wire locations, 3–37
- SCSI ID switches
 - TLZ06, 3–42
- Signal distribution, 1–9
- Site preparation, 2–1
- Space requirements, 2–7
- Spare parts
 - list of, B–1
- Standard Ethernet
 - loopback connector, 2–12
- Static electricity
 - See* ESD, 2–3
- Storage conditions, 2–4
- Support plate
 - separating, 3–11
- Synchronous communications options
 - list of, 1–16
 - removing, 3–54
 - spare parts for, B–1
- System configuration
 - guidelines for, 1–10
- System loopback connectors, B–1

System unit
air exhaust, 1–10
air intake, 1–10
clearance, 2–7
connectors, 1–3, 2–7
controls, 1–3
dimensions, 2–1
indicators, 1–3
ports, 1–3, 2–7
spare parts for, B–1
turning on, 2–14

T

Tape drive
TLZ06, removing, 3–38
TZ30, removing, 3–29
TZK10, removing, 3–33

Temperature
nonoperating, 2–4
operating, 2–4

storage, 2–4

Terminator
ThinWire Ethernet, 2–10

TLZ06 tape drive
mounting bracket, 3–41
option switches, 3–42
removing, 3–38
SCSI ID setting, 3–42

TZ30 tape drive
mounting bracket, 3–31
removing, 3–29
SCSI ID setting, 3–32

TZK10 tape drive
mounting bracket, 3–36
removing, 3–33
SCSI ID setting, 3–37

U

Upper drive-mounting shelf
removing, 3–19

